

LD Cart Transporter

User's Guide



Copyright Notice

The information contained herein is the property of Omron Adept Technologies, Inc., and shall not be reproduced in whole or in part without prior written approval of Omron Adept Technologies, Inc. The information herein is subject to change without notice and should not be construed as a commitment by Omron Adept Technologies, Inc. The documentation is periodically reviewed and revised.

Omron Adept Technologies, Inc., assumes no responsibility for any errors or omissions in the documentation. Critical evaluation of the documentation by the user is welcomed. Your comments assist us in preparation of future documentation. Please submit your comments to: techpubs@adept.com.

Copyright © 2016 - 2019 by Omron Adept Technologies, Inc. All rights reserved.

Any trademarks from other companies used in this publication are the property of those respective companies.

MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson.

Copyright 2012 CEPSTRAL LLC <http://www.cepstral.com> This product may contain copyright material licensed from CEPSTRAL LLC, all right reserved.

This manual was originally written in English.

Created in the United States of America

Table of Contents

Chapter 1: Introduction	11
1.1 Definitions	11
1.2 Product Description	11
LD Platform Cart Transporter	13
Cart	16
Coupling	16
Optional Components	16
User-Supplied Components / System Requirements	17
1.3 Software Overview	17
Mobile Robot Software Suite	17
SetNetGo	19
1.4 How Can I Get Help?	19
Related Manuals	19
Support	19
Including a DebugInfo File	19
Chapter 2: Safety	23
2.1 Dangers, Warnings, and Cautions	23
Alert Levels	23
Alert Icons	23
Falling Hazards	24
Special Information	24
2.2 What to Do in an Emergency /Abnormal Situation	24
Releasing the Brakes	24
Releasing an E-Stop	25
2.3 Safety Precautions	25
User's Responsibilities	25
General Hazards	26
Electrical Hazards	26
Pinch and Entanglement Hazards	27
Magnetic Field Hazards	28
Qualification of Personnel	28
Payload Movement and Transfer	29
Configurable Warning Buzzer	29
Multi-AIV Avoidance	29
Traffic Control	30
Passing Lanes	30
2.4 Environment	30
General Environmental Conditions	30

Public Access	30
Clearance	30
Obstacles	31
Safety Scanning Laser Emergency Stop	31
Safety System Overspeed Faults	31
2.5 Intended and Non-intended Use	32
Intended Use	32
Non-Intended Use	32
Platform Modifications	33
2.6 Battery Safety	33
2.7 Additional Safety Information	34
Accidental Cart Separation	34
Mobile Robot LD Safety Guide	34
2.8 Disposal	34
Chapter 3: Setup	35
Overview	35
Tasks	35
3.1 Transport and Storage	35
LD Platform Cart Transporter	36
Battery	36
Standalone Cart	36
3.2 Before Unpacking	37
3.3 Unpacking	37
Battery	37
LD Platform Cart Transporter	39
Repacking for Relocation	42
3.4 Setting Up an LD Platform Cart Transporter	42
Rolling the LD Platform Cart Transporter off of the Crate Base	43
Installing the Battery	45
Installing the Docking Station	49
3.5 Installing the Cart Brake Release	54
Installation	55
Adjustment	59
Chapter 4: Configuration	61
4.1 Settings and Configuration	61
Maintenance Ethernet Connection	61
Setting Up Wireless Ethernet	63
4.2 Mapping	65
Mapping Overview	65
Mapping Tasks	65
Setting Up Cart-Parking Goals	66

Marking Cart-Parking Goals on Floor	66
4.3 Configuring a Touchscreen	66
Touchscreen Ethernet Setup	66
Operating Modes	67
Localization Goals	69
Screen Logo	70
Screensaver	71
Display Language	72
Contact Information	73
4.4 Acceleration, Deceleration, and Rotation Limits	73
4.5 Supplemental Information	74
Laser Setup	74
Chapter 5: Payloads	75
5.1 Safety	75
Warning Label	75
Drive Warning Light	75
Turn Warning Lights	75
Warning Buzzer	75
5.2 Considerations	76
Dimensions	76
Pinch Hazard	76
Weight	76
Center of Gravity	76
5.3 Payload-Related Tradeoffs	81
Chapter 6: Connectivity	83
6.1 Required Connections	83
6.2 LD Platform Cart Transporter Connections	83
Core	83
Cart-Specific PCA	84
6.3 Standard Platform Connections	89
LD Platform Core Front, Upper	90
LD Platform Core Rear, Upper	96
Internal LD Platform Core Connections	105
Core Internal Data Pinouts	106
LD Platform Core Internal Power Pinouts	108
Chapter 7: Operator Interface	111
7.1 Touchscreen	111
Touchscreen Initialization	111
Touchscreen Configuration	112
Screen Top Bar	112

Left Screen Pane	112
Right Screen Pane	114
Center Pane	118
Relocalization	118
Choose Dropoff Mode	118
Patrol Route Mode	121
7.2 Operator Panel	122
E-Stop Button	122
ON Button	123
OFF Button	123
Brake-release (BRAKE) Button	123
Keyswitch	123
LATCH Button	123
UNLATCH Button	124
7.3 Other Controls and Indicators	124
Light Discs and Beacon	124
LD Platform Core Indicators	128
Battery and Docking Station	129
Chapter 8: Operation	131
8.1 Operating Environment	131
Intended Use	131
Clearance	131
Obstacles	131
Environment and Floor	132
Platform Getting Stuck	132
Cart Getting Stuck on Platform	133
8.2 Typical Operation	133
8.3 Power and Charging	134
Battery Indicators and Controls	134
Docking Station	135
Manually Charging the Battery	137
Balancing the Battery	137
8.4 Startup	139
Procedure	139
Joystick	139
8.5 Working with Carts	140
Goals	140
Operation	140
Cart-Locating	140
Cart Brakes	140
Chapter 9: Options	143
Enterprise Manager	143
MobilePlanner Software (licensed)	143

Joystick	143
Spare Battery	143
Spare Carts	143
Call Buttons/Door Boxes	143
Acuity Localization	144
High-Accuracy Positioning System	144
Chapter 10: Maintenance	145
10.1 Safety Aspects While Performing Maintenance	147
Electrical Hazards	147
Burn Hazard	147
Pinch Hazard	147
Magnetic Field Hazards	148
10.2 Safety Measures Prior and After Maintenance	148
10.3 Lifting the Platform Safely	148
Front Lifting Points	148
Rear Lifting Area	149
10.4 Safety Inspection	150
Warning Devices	150
Warning Labels	150
Informative Labels	153
10.5 Cleaning	154
Work Area Maintenance	154
LD Platform Cart Transporter and Cart	154
Tires	155
Casters	155
Axles	155
Lasers	155
Docking Station Contacts	156
10.6 Accessing the Payload Bay	156
Removing Latching Mechanism Cover	156
Removing Top Plate	156
Installing Top Plate	158
Installing Latching Mechanism Cover	158
10.7 Removing and Installing LD Platform Cart Transporter Covers	158
Removing Covers	159
Installing Covers	162
10.8 Replacing Periodic Parts	164
Maintaining and Replacing Batteries	165
Maintaining Batteries	165
10.9 Replacing Non-Periodic Parts	166
Docking Station Roller and Bearing	166
Docking Station AC Power Fuse	167
Docking Station Internal Fuse	168

Safety Scanning Laser	169
Obstacle Detection and Coupling Lasers	169
Rear Sonar Units	169
Sonar Controller	170
Cart Latching Mechanism	171
Light Discs	173
Operator Panel	173
Wheels and Tires	173
Drive Assemblies	174
Platform Casters	177
Cleaning Casters on ESD Platforms	179
LD Platform Cart Transporter Casters	179
Cart Brake Release	182
LD Platform Core	184
E-Stop and Safety Laser Commissioning	185
Chapter 11: Technical Specifications	187
11.1 Dimension Drawings	187
11.2 Specifications	188
LD Platform Cart Transporter Physical	188
LD Platform Cart Transporter Performance	189
Battery Output	190
Cart	191
Docking Station	191

Revision History

Revision Code	Date	Revised Content
01	April, 2017	Original releas
02	March, 2017	Added 2-second delay after E-Stop recovery; dimensions updated; MaxVelxxx parameters updated; removed procedure for user replacement of wheels and tires; changed pacemaker/magnet warning to say medical implant; changed gap and step specs; added instructions for unlatching a cart that is stuck to a transporter; clarified that max payload does NOT include the cart itself; use of joystick warning modified.
03	September, 2017	Update product name, battery specifications, and image of joystick. Added instructions for updated shipping crate. Regulatory changes, specification changes, and E-stop instruction clarifications.
04	November, 2017	Clarify that the material on the Latching Mechanism is acetal. Removed sentence with example regarding safety laser commissioning speed zones.
05	February, 2018	Update format of safety chapter. Update warning alert levels throughout user guide. Update navigation laser height from 201 mm to 200 mm. Update "No Riding" and "No Incline" labels.
06	February 2019	Updated format of Chapter 1. Added WEEE icon and Disposal section to Safety chapter (this section only applies to English version of this manual). Applied English condition to www.ia.omron.com . Copyright date updated to include 2019. Added a note to Physical Barriers section that barrier's height recommendation is 250 mm. Added a note to User Interface section, regarding flipping E-stop switch very quickly. Reworded Physical Barriers section. Reworded Battery Indicators and Controls table (call out C). Changed wording of LED lights blinking in Battery Indicators and Controls section. Added Windows 10 Network Setup information. Added a note regarding damp floors in Intended Use section. Updated "Driving Slowly, E-Stop Inactive" section. Revised Battery Life Cycle to " Approximately 2000 Cycles". Made Enterprise Manager generic (removed 1100), except in Related Manuals section. Added " Safety System Overspeed Faults" section. Removed "Limit to <5 A per Pin" in User Power section and reworded the note regarding 10A of current. Updated "Autonomous Charging" section, and also noted that AIVs can be turned off while on the docking station. Revised transportation and storage temperature to -20 to 60°C. Revised Battery Indicators and Controls section wording. Updated manual for translation. Prepared graphics (changed text in graphics to callouts. Deleted low front laser removal instructions. Added Docking Station Internal Fuse section. Added Docking Station AC Power Fuse section. Added a figure to Sonar Controller section. Revised Maintaining and Replacing Batteries section. Added Operator

Revision Code	Date	Revised Content
		Panel section. Added a figure to Removing and Installing LD Platform Cart Transporter Covers section. Added a paragraph to Bandwidth Considerations section. Updated format of Mapping section. Revised wording of the first paragraph in Acceleration, Deceleration, and Rotation Limits section. Added Warning Label section and Warning Buzzer section to Payload chapter. Added two notes to Internal LD Platform Core Connections section. Took a note regarding battery safety out of Setup chapter and placed in Safety chapter (Battery Safety section). Added a section to Maintenance chapter regarding applying E-stop and powering off the robot, prior and after maintenance.

Chapter 1: Introduction

This manual covers the setup, operation, and user maintenance of an LD Platform Cart Transporter and cart.

The basic configuration performed using the software that comes with the system is covered. Full details of that configuration are covered in the *Mobile Robot Software Suite User's Guide*.

1.1 Definitions

Platform: The most basic part of the robot. It includes the chassis, drive assemblies, suspension, wheels, battery, safety scanning laser, obstacle-avoidance lasers, sonar, an on-board LD Platform core with built-in gyroscope, software needed to navigate, connectors for interfacing with and powering the Operator panel and cart coupling system, Operator panel, and the platform covers.

LD Platform Cart Transporter: A platform with the LD Platform OEM (including extended arms) and the coupling plate attached, set up to transport a cart. This is also referred to as just a transporter.

Cart: A cart, on four casters, that can be attached to an LD Platform Cart Transporter, for increasing the payload capacity. The cart has brakes on two casters, which can be released either by coupling with a transporter, or by using a manual brake-release lever on the cart.

AIV (Autonomous Intelligent Vehicle): The LD Platform Cart Transporter with a cart attached to it. This is the complete mobile robot, which will transport your payload on the cart.

For the initial setup, configuration, and connections, we will refer to the platform.

For controlling or monitoring the full mobile robot, with a cart attached, we will refer to the AIV.

1.2 Product Description

The LD Platform Cart Transporter is a general-purpose mobile platform designed for moving a detachable cart indoors and around people. It is self-guided and self-charging, with an automated docking station.

The platform, which moves the cart, comes complete with the ability to know where it is within your workspace, and to navigate safely and autonomously to any accessible destination within that workspace, continuously and without human intervention.

The LD Platform Cart Transporter is intended to expand the range of payloads that can be moved by a platform, both in weight and size.

The LD Platform Cart Transporter is available in two models, designed to transport carts with a payload up to 105 kg (231 lb) for the LD-105CT and 130 kg (287 lb) for the LD-130CT platform. Where appropriate, differences between the models are called out. Otherwise, this manual applies to both LD Platform Cart Transporters.



Figure 1-1. Cart and LD Platform Cart Transporter, Separate



Figure 1-2. Cart and LD Platform Cart Transporter, Coupled




Figure 1-3. LD Platform Cart Transporter Model Labels

LD Platform Cart Transporter

The LD Platform Cart Transporter is a mobile platform, designed for working around people while moving a cart. It is self-guided and self-charging, with an automated docking station. The transporter combines hardware and mobile-robotics software to provide an intelligent, mobile platform to transport your payload on the cart. Its primary guidance uses a safety scanning laser to navigate, comparing the laser readings to a digital map stored on the platform. The laser is backed up by a gyroscope mounted on the internal core, and encoders and Hall sensors on each drive wheel.

In addition to the front safety scanning laser, each LD Platform Cart Transporter has two side lasers, for detecting potential obstacles in its path, a low front laser in the bumper to detect obstacles lower than the safety scanning laser, and a rear-facing obstacle-detection laser, to ensure that it is safe for the transporter to back up or turn in place.

For situations that are so dynamic that laser localization becomes difficult, we offer the Acuity Localization option, which localizes the AIV using an upward-facing camera to recognize overhead lighting patterns. This would apply to areas where objects, such as pallets or carts, are moved so frequently that they can't be mapped, or where they block the laser's view of features that are mapped. This is covered in the *LD Platform Peripherals Guide*.

Body and Drive

The LD Platform Cart Transporter is relatively small, lightweight, and highly maneuverable. It has a strong aluminum chassis and solid construction that makes it very durable.

The platform is a two-wheel, differential-drive vehicle, with spring-loaded passive casters front and rear for balance. The drive-wheels have independent spring-suspension, with solid, foam-filled tires. The wheels are at the mid-line of the platform, so that the platform can turn in place.

Safety Scanning Laser

The onboard navigation laser is a very precise scanning sensor. The laser provides 500 readings in a 240 degree field of view, with a typical maximum range of 15 m (49.2 ft). The laser

operates in a single plane, positioned at 200 mm (7.9 inches) above the floor. In most environments, the sensor will provide highly-accurate data.

Glass, mirrors, and other highly-reflective objects cannot be reliably detected by the laser. Caution must be exercised when operating the AIV in areas that have these types of objects. If the AIV will need to drive in close proximity of these objects, we recommend that you use a combination of markings on the objects, such as tape or painted strips, and also use forbidden sectors in the map, so that the AIV knows to plan paths safely around these objects.

Side Lasers

These two lasers are used to detect obstacles that protrude into the AIV's path, but may not be detected by the safety scanning laser.

This is needed when obstacles higher than the safety scanning laser (but low enough to be obstacles) protrude into the AIV's path.

Low Front Laser

This laser is mounted to the front bumper. It detects obstacles that are low and in front of the transporter, such as an empty pallet, which might be too low for the safety scanning laser to see.

Rear-Facing Laser

This laser gives better coverage of what's behind the transporter than sonar alone. It is used during both turning in place and backing up when the transporter and cart are coupled.

Coupling Laser

A laser mounted in the transporter coupling plate is used to locate a triangle on the underside of the cart's coupling plate. This is used by the transporter to accurately align with the cart, so it can couple with it.

Sonar

The LD Platform Cart Transporter's two rear-facing sonar pairs are for obstacle-sensing while backing up. The range is up to 5 m (16 ft), though the typical accurate range is only about 2 m (10 ft). Each pair consists of one emitter and one receiver. The sonar emitters and receivers are identical physically, but the transporter uses them differently.

Encoders and Gyroscope

Each wheel has an encoder that tells the navigation system how far the wheel has turned, and in which direction. Each wheel also has a Hall sensor.

The LD Platform core has a gyroscope mounted on it, to track the AIV's rotation.

The combination of rotation and distance traveled are used by the platform to back up the safety scanning laser during localization. These limit the area on the platform's map that the AIV needs to search when localizing.

What's Included with an LD Platform Cart Transporter

- One fully-assembled platform

The platform includes a safety scanning laser, a low front laser, two side lasers, a rear-facing laser, and two rear-facing sonar pairs. Each pair is one transmitter and one receiver.

- One battery

This is shipped separately from the platform, due to air shipping regulations.

If the battery was shipped by air, it will be at less than 30% charge per IATA regulations.

- Top plate and coupling plate

The platform top plate covers the payload bay of the platform, and supports the lower (platform) coupling plate, which engages the cart coupling plate, attached to the cart, and the coupling laser.

- LD Platform core, which includes an integrated computer, running Advanced Robotics Automation Management (ARAM) and a microcontroller with MARC firmware. The core is housed inside the platform. It also runs the SetNetGo OS.

ARAM and MARC firmware and the SetNetGo OS are pre-loaded on the LD Platform Core.

- An HMI Post

This supports the two side lasers and the rear-facing laser, both for obstacle avoidance. It also supports the Operator Panel.

- Operator Panel

This includes a touchscreen, an E-Stop button, ON and OFF buttons, a brake-release button, and a keyswitch, which can be locked, and key removed, in either position. The panel's frame supports two WiFi antennas and a beacon.

There are LATCH and UNLATCH buttons below the E-Stop.

The optional Acuity Localization camera mounts on top of the Operator panel frame, on the same plane as the antennas and beacon.

- Automated docking station

This allows the LD Platform to charge itself, without user intervention. It includes a wall-mount bracket and a floor plate, for a choice of installation methods. See Installing the Docking Station on page 49.

A manual charging cord is included, so you can charge a spare battery outside of the platform.

- Joystick (option)

This is used for manually controlling the AIV, mostly when making a scan to be used for generating a map.

At least one joystick is needed for each fleet of AIVs. Once a map is generated, the map can be shared with multiple AIVs working in the same space.

Cart

The cart is a frame mounted on four casters, designed so that it can couple with an LD Platform Cart Transporter. Once coupled, the cart moves with the transporter. When the transporter arrives at the intended goal, it uncouples from the cart and leaves, while the cart remains at the goal. Brakes automatically engage on the cart casters, preventing it from rolling in case the floor isn't completely level.

The cart has a manual brake-release lever, so it can be moved manually.

Coupling

The LD Platform Cart Transporter can attach to a cart at a pickup goal, move the cart to a dropoff goal, and leave it at that goal, with no human intervention.

When the cart and transporter are coupled, the transporter automatically presses a lever that releases the cart's brakes, so it is free to move with the transporter.

The coupling system has:

- a motorized Latching Mechanism
- a coupling laser
This is mounted in the coupling plate, and is used to align the transporter with the cart when coupling.
- LATCH and UNLATCH override buttons, on the Operator Panel

Coupling Plates

Each cart has one coupling plate, and each platform has one coupling plate. The plates are mounted so that, when the platform moves under the cart, the plates can attach to each other, allowing the platform to move the cart. The software is aware of whether or not a cart is attached.

- The cart coupling plate includes a slot that can be latched with the platform coupling plate. The cart coupling plate is passive.
- The platform coupling plate includes a laser, for aligning the platform before coupling, and a motorized Latching Mechanism, for latching the cart coupling plate.

Optional Components

Refer to Options on page 143 for details.

- Acuity Navigation
For environments that are very dynamic, such that a map can't be kept current, or where the area is too large for the navigation laser to see, Acuity can be used to navigate using overhead light patterns seen with an upward-facing camera.
- Enterprise Manager
This system manages a fleet of AIVs, for multi-AIV traffic coordination and job management. It includes the Enterprise Manager appliance running the Mobile Software suite.

- Spare battery

A spare battery can be used to minimize down-time. Swapping the battery for a fully-charged battery avoids taking the AIV out of service for more than a few minutes.

- Call/Door Boxes

These allow an AIV to be requested from a remote location, or allow the AIV system to control an automated door, so the AIV can pass through it.

User-Supplied Components / System Requirements

PC with Microsoft Windows®

- Ethernet (wireless preferred)

Wireless is required for a fleet (more than one AIV).

- 100 megabytes of available hard-disk storage

1.3 Software Overview

Mobile Robot Software Suite

The Mobile Robot Software Suite includes all of the software used for platforms and the Enterprise Manager appliance, with the exception of the SetNetGo OS.

ARAM

The Advanced Robotics Automation Management software (ARAM) runs on the LD Platform core. It operates ranging sensors like the safety scanning laser and sonar, and performs all the high-level, autonomous robotics functions, including obstacle avoidance, path planning, localization, navigation, and so on, culminating in motion commands to the MARC firmware. ARAM also controls the battery and light discs, and manages digital and analog I/O, which, along with platform power, provide for integration of application-specific sensors and effectors that the user adds.

ARAM manages wired and wireless Ethernet communications with offboard software, for external monitoring, development, and systems coordination, including coordination of a fleet of AIVs through the optional Enterprise Manager . It also manages integration with other systems, as well as external monitoring, setup, and control with the MobilePlanner application.

ARAMCentral

ARAMCentral is the software that runs on the Enterprise Manager appliance. This software and the appliance combined are referred to as Enterprise Manager.

For a fleet, the ARAMCentral software manages:

- the map that all AIVs use
- the configuration that all AIVs use
- traffic control of the AIVs

This includes multi-AIV avoidance, destination, standby, and dock control.

- queuing of jobs for the AIVs
- remote I/O, if you are using it

MobilePlanner (licensed)

In order to have your AIV perform autonomous mobile activities, you need to make a map of its operating space, and configure its operating parameters. The MobilePlanner software is used to make this map and perform this configuration.

Refer to the separate *Mobile Robot Software Suite User's Guide* for details on how to map a working space and prepare the virtual elements, goals, routes, and tasks for your application. In particular, refer to:

Working With Map Files > Editing a Map File > Using the Drawing Tools > Adding Goals and Docks

The MobilePlanner software requires a license to run. You will need at least one license for MobilePlanner for each fleet of AIVs. Once you generate a map for an area, it can be shared between multiple AIVs in one fleet.

MobilePlanner, Operator Mode

The MobilePlanner Operator Mode is used to monitor one or more AIV's activities and have them perform mobile tasks in the mapped space. When MobilePlanner is started without its license dongle, it automatically starts in this mode. Refer to the separate *Mobile Robot Software Suite User's Guide* for details.

Mobile Adept Robot Controller (MARC)

At the lowest level, a microcontroller running MARC firmware handles the details of platform mobility, including maintaining the platform's drive speed and heading, as well as acquiring sensor readings, such as from the encoders and gyroscope, and managing the platform's emergency stop systems, bumper, and joystick. The MARC firmware computes and reports the platform's odometry (X, Y, and heading) and a variety of other low-level operating conditions to ARAM.

Touchscreen Support

Whenever the Mobile Software suite is downloaded, it includes support software for the optional touchscreen.

Call/Door Box Support

Call/Door boxes have one software component on the box and another on either the Enterprise Manager or on the single AIV, when there is no Enterprise Manager.

ARCL Protocol

ARCL is a function of ARAM and ARAMCentral, which is included as part of this suite.

The Advanced Robotics Command Language, or ARCL, is a simple text-based command and response server for integrating an AIV (or fleet of AIVs) with an external automation system.

ARCL allows you to operate and monitor the AIV, its accessories, and its payload devices over the network, with or without MobilePlanner.

SetNetGo

The SetNetGo OS runs on the LD Platform core and Enterprise Manager appliance. It is the host OS in which ARAM and ARAMCentral run.

The SetNetGo interface in the MobilePlanner software is used for configuring the Ethernet settings for the platform, upgrading software, and performing systems diagnostics, such as retrieving log files. It can be accessed when connected via the maintenance and management Ethernet ports, or via wireless Ethernet if enabled.

NOTE: It is possible to connect directly to the SetNetGo OS on a platform through a web browser. The main intent of this is to allow your IT support to set up the network for you, without using MobilePlanner, which requires a license.

1.4 How Can I Get Help?

Refer to the corporate website:

<http://www.ia.omron.com>

Related Manuals

This manual covers the installation, setup, operation, and maintenance of an LD Platform Cart Transporter. There are additional manuals that cover these actions for the platform.

Table 1-1. Related Manuals

Manual Title	Description
<i>Mobile Robot LD Safety Guide</i>	Contains general safety information for all of our LD Platforms.
<i>Mobile Robot Software Suite User's Guide</i>	Covers MobilePlanner software, the SetNetGo OS, and most of the configuration of an LD Platform.
<i>Enterprise Manager 1100 User's Guide</i>	Covers the Enterprise Manager 1100 system, which is hardware and software used for managing a fleet of AIVs.
<i>LD Platform Peripherals Guide</i>	Covers peripherals, such as the Touchscreen, Call/Door box, and Acuity Localization options.

Support

If, after reading this manual, you are having problems with your LD Platform Cart Transporter, contact your local Omron support.

- In the body of your e-mail message, provide your platform's serial number and describe the problem you are having in as much detail as possible.
- Attach your debuginfo file to the email. Refer to the next section for details on retrieving your debuginfo file. See the following section for generating your debuginfo file.

Including a DebugInfo File

If the platform has been set up on a wireless network, skip to SetNetGo Access on page 20.

Network Setup


If the AIV has not been set up on a wireless network, a local area network will have to be set up on a separate PC, and configured to talk to the AIV over a TCP/IP port. The IP address should be set to: 1.2.3.5. The Subnet Mask should be 255.255.255.0.

(Windows 7) **Start > Control Panel > (Network and Internet >) Network and Sharing Center > Change adapter settings**

(Windows 10) **Start > Settings > Network and Internet > Change adapter options**

Right-click on the **LAN Connection**, and click on **Properties**.

From the Properties dialog, scroll to and double-click the **Internet Protocol (TCP/IP or TCP/IPv4)** option. In Internet Protocol Properties, click both "Use the following..." radio buttons to enable them, and then type in the IP and netmask values.




Connect the network port of your computer to the platform's Maintenance port. See the figure Location of Parts in the Payload Bay on page 146.

SetNetGo Access

If the MobilePlanner software is available, use the SetNetGo interface within that software to access SetNetGo. Otherwise, open a web browser and enter the URL: <https://1.2.3.4>:

You will be requested to confirm security certificates.

Regardless of how you accessed SetNetGo, you should now have a window similar to the following:



1. From the SetNetGo screen, select:

Status > Debug Info

This will display the “Download debug info” button.

2. Click Download debug info.
3. Save the downloaded file, and attach it to your support request.

Chapter 2: Safety

2.1 Dangers, Warnings, and Cautions

Alert Levels

There are three levels of alert notation used in our manuals. In descending order of importance, they are:



DANGER: Identifies an imminently hazardous situation which, if not avoided, is likely to result in serious injury, and might result in fatality or severe property damage.



WARNING: Identifies a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, and might result in serious injury, fatality, or significant property damage.




CAUTION: Identifies a potentially hazardous situation which, if not avoided, might result in minor injury, moderate injury, or property damage.

Alert Icons

The icon that starts each alert can be used to indicate the type of hazard. These will be used with the appropriate signal word - Danger, Warning, or Caution - to indicate the severity of the hazard. The text following the signal word will specify what the risk is, and how to avoid it.

Icon	Meaning	Icon	Meaning
	This is a generic alert icon. Any specifics on the risk will be in the text following the signal word.		This identifies a hazardous entanglement situation.
	This identifies a hazardous electrical situation.		This identifies a fire risk.
	This identifies a hazardous burn-related situation.		This identifies a laser emitter eye damage situation.

Icon	Meaning	Icon	Meaning
	This identifies a hazardous ESD situation.		

Falling Hazards



WARNING: PERSONAL INJURY OR PROPERTY DAMAGE RISK

The AIV can cause serious injury to personnel or damage to itself or other equipment if it drives off of a ledge, such as a loading dock, or down stairs.

Physical Barriers

The edge of a loading dock, the entrance to downward stairs, or any other substantial drop that is within the AIV's expected operating area should be physically marked so that the AIV's navigation laser will see the barrier, and stop before reaching it. The AIV is designed to detect objects 200 mm tall, so the barrier must be at least that tall. However, because of variations in floor flatness, we recommend a barrier that is 250 mm tall.

This needs to be continuous at the site, so that the AIV can't drive around or through it to the dropoff.

Special Information

There are several types of notation used to call out special information.

IMPORTANT: Information to ensure safe use of the product.

NOTE: Information for more effective use of the product.

Additional Information: Offers helpful tips, recommendations, and best practices.

Version Information: Information on differences in specifications for different versions of hardware or software.

2.2 What to Do in an Emergency /Abnormal Situation

Press the E-Stop button (a red push-button on a yellow background) and then follow the internal procedures of your company or organization for an emergency /abnormal situation. If a fire occurs, use a type D extinguisher: foam, dry chemical, or CO₂.

Releasing the Brakes

In case of an emergency or abnormal situation, the transporter can be manually moved. However, only qualified personnel who have read and understood this manual and the *Mobile Robot LD Safety Guide* should manually move the transporter. The brakes on the drive wheels can be released with the brake release button. This requires battery power, and an E-Stop must be pressed on the transporter.

Version Information: The LD-130CT has a high gear ratio, and is difficult to move, even with the brakes released.

Releasing an E-Stop



CAUTION: PERSONAL INJURY OR PROPERTY DAMAGE RISK

If the AIV's E-Stop is triggered, ensure that the cause of the E-Stop is resolved, and all surrounding areas are clear releasing the E-Stop.

After the E-Stop button has been manually released, the AIV will wait until the motors are manually enabled.

There are two ways to enable the motors:

- Using MobilePlanner
- Pressing the green ON button on the Operator Panel or the GO button on the Touch-screen

Once the motors are enabled, the transporter will wait two seconds and then resume commanded motion, if there is adequate space to maneuver.

2.3 Safety Precautions



WARNING: PERSONAL INJURY OR PROPERTY DAMAGE RISK

LD Platform robots can cause serious injury or death, or damage to itself and other equipment, if the following safety precautions are not observed.



WARNING: ELECTROCUTION RISK

During maintenance, disconnect AC power from the robot, and install a lock-out tag-out to prevent anyone from reconnecting power.

User's Responsibilities

It is the end-user's responsibility to ensure that the AIVs are used safely. This includes:

- Reading the installation and operation instructions, as well as the Mobile Robot LD Safety Guide, before using the equipment.
- Ensuring that the environment is suitable for safe operation of the AIV.

If a fleet of AIVs (two or more) is installed, the Enterprise Manager must be used, unless no two AIVs will ever operate in the same area.

- Ensuring that anyone working with or near an AIV has been adequately trained, and is following this user's guide and the Mobile Robot LD Safety Guide, for safe AIV operation.
- Maintaining the AIVs so that their control and safety functions are working properly.

General Hazards

IMPORTANT: The following situations could result in minor injury or damage to the equipment.

- Do not ride on the platform or cart.
- Do not exceed the maximum weight limit.
- Do not exceed the maximum recommended speed, acceleration, deceleration, or rotation limits. See Center of Gravity on page 76 and Acceleration, Deceleration, and Rotation Limits on page 73.

Rotational speed becomes more significant when the payload's center of gravity is farther away (vertically and/or horizontally) from the platform's center of gravity.

- Do not drop the AIV, run it off a ledge, or otherwise operate it in an irresponsible manner.
- Do not allow the AIV to drive through an opening that has an automatic gate/door unless the door and AIV are configured correctly with the Door Box option.

Refer to the *LD Platform Peripherals Guide* for details on the Door Box.

- Do not get the AIV wet. Do not expose the AIV to rain or moisture.
- Do not continue to run the AIV after hair, yarn, string, or any other items have become wound around the platform's axles, casters, or wheels.
- Do not use parts not authorized by Omron Adept Technologies, Inc.
- Do not turn on the AIV without the antennas in place.
- Although the lasers are Class 1 (eye-safe), we recommend you not look directly into them.

Logical Barriers

You should also use forbidden areas, sectors, or lines with several feet of safety zone (padding) before the actual dropoff, to ensure that the AIV will not try to drive there.

These need to be continuous at the site, so that the AIV can't plan a path to drive around or between them to the dropoff.

Electrical Hazards



WARNING: ELECTROCUTION RISK

The docking station has AC power inside. Its covers are not interlocked.

- Do not use power extension cords with the docking station unless properly rated.
- Never access the interior of the platform with the docking station attached.
- Immediately disconnect the battery after opening the battery compartment door.

Avoid shorting the battery terminals.

- Do not use any charger not supplied by Omron Adept Technologies, Inc.
- If any liquid is spilled on the AIV, power off the AIV, clean up all possible liquid, and allow the AIV to air dry thoroughly before restoring power.

Pinch and Entanglement Hazards

Latching System Latch



CAUTION: PINCH RISK

The latch of the LD Platform Cart Transporter can pinch you if you are not careful. Keep your hands clear of the transporter when it is in action.

Latching System Belt/Pulley



CAUTION: PINCH RISK

During maintenance on the latch mechanism, the belt and pulley can pinch you if you are not careful. Keep your hands clear of the belt and pulley when they are in action.



WARNING: ENTANGLEMENT RISK

The belt and pulley of the LD Platform Cart Transporter can entangle your hand during maintenance. Keep your hands clear of the belt and pulley when they are moving.

HMI Post-Cart Gap



CAUTION: PINCH RISK

The coupling action of the LD Platform Cart Transporter and cart can pinch you if the cart payload is incorrectly designed, and you are not careful. Keep your hands clear of the space between the HMI post and cart when the platform and cart are coupling.

Platform Covers



CAUTION: PINCH RISK

The covers are held in place with strong magnets, which can pinch you if you are not careful. Follow the instructions in the Maintenance chapter for handling covers.

IMPORTANT: The hazard presented by the platform cover magnets is slight enough that the covers and their magnets do not have warning labels.

Magnetic Field Hazards

Platform Covers



WARNING: MAGNETIC FIELD - MEDICAL IMPLANT RISK

Magnetic fields can be hazardous to medical implant wearers. Medical implant wearers stay back 30 cm (12 inches) from the covers, which are held in place with strong magnets.

Docking Funnel



WARNING: MAGNETIC FIELD - MEDICAL IMPLANT RISK

Magnetic fields can be hazardous to medical implant wearers. Medical implant wearers stay back 30 cm (12 inches) from the underside of the platform, which is exposed when the platform is tipped on its side during maintenance.

Cart Magnet

The underside of the cart has a strong magnet, used to signal the LD Platform Cart Transporter that it is in place. This can be a hazard to medical implant wearers, if they get too close to it.



WARNING: MAGNETIC FIELD - MEDICAL IMPLANT RISK

Magnetic fields can be hazardous to medical implant wearers. Medical implant wearers stay back 30 cm (12 inches) from the bottom of the cart.

Qualification of Personnel

It is the end-user's responsibility to ensure that all personnel who will work with or around AIVs have attended an appropriate Omron training course and have a working knowledge of the system. The user must provide any necessary additional training for all personnel who will be working with the system.

As noted in this and the Mobile Robot LD Safety Guide, certain procedures should be performed only by skilled or instructed persons. For a description of the level of qualification, we use the standard terms:

- **Skilled persons** have technical knowledge or sufficient experience to enable them to avoid the dangers, electrical and/or mechanical
- **Instructed persons** are adequately advised or supervised by skilled persons to enable them to avoid the dangers, electrical and/or mechanical

All personnel must observe industry-prescribed safety practices during the installation, operation, and testing of all electrically-powered equipment.

IMPORTANT: Before working with the AIV, every entrusted person must confirm that they:

- Have the necessary qualifications
- Have received the guides (both this guide, and the Mobile Robot LD Safety Guide)
- Have read the guides

- Understand the guides
- Will work in the manner specified by the guides

Payload Movement and Transfer

Monitoring and confirmation of the status of AIV payload movement and transfer to or from facility equipment is the end-user's responsibility.

Payload transfer problems must trigger an AIV E-Stop, preventing the AIV from moving until an Operator has resolved the problem and confirmed that the system is safe to use. This handling of payload transfer problems is the end-user's responsibility.

Providing an interlock between the AIV and facility equipment is the user's responsibility.

Configurable Warning Buzzer

The LD Platform Cart Transporters have a configurable warning buzzer. It is the user's responsibility to configure this buzzer as appropriate for the facility in which the AIV will be operating. The buzzer will sound whenever the AIV is moving backwards or is turning. Other situations are configurable.

The buzzer is configured with MobilePlanner, using the following parameters:

NOTE: These parameters are only available with the Mobile Robot Software Suite 5.0 and later.

Table 2-1. Default Parameters

Parameter	Default Setting
DriveWarningEnable	True NOTE: If this parameter is set to False, the remaining parameters will not be displayed. IMPORTANT: Disabling the <i>DriveWarningEnable</i> parameter violates the JIS D 6802 standard. It is strongly recommended that you leave this set to True.
DoNotWarnDrivingForwards	False
DoNotWarnTurningInPlace	False
DriveWarningLoudMilliseconds	500; If <i>DriveWarningQuietMilliseconds</i> is 0, this parameter is irrelevant.
DriveWarningQuietMilliseconds	500; This is the length of time between warnings that the buzzer is silent. Setting this to 0 will cause a continuous warning.

Multi-AIV Avoidance

When multiple AIVs are operating in the same operating space, they must be connected to an Enterprise Manager (EM) via WiFi. The EM helps prevent collisions by sharing AIVs'

dynamic X, Y, Theta, size, and path-planning information with each other. AIVs then factor this data into their obstacle avoidance. This is not an interlocked method of preventing collisions. Ultimately, it is the end-user/integrator's responsibility to provide an interlocked method of preventing collisions.

NOTE: If two AIVs are approaching each other, neither will see the other because the incoming laser beams are detected as reflected beams. Because of this, any installation with more than one AIV working in the same operating space must be managed by the same Enterprise Manager.

Traffic Control

A "switchable forbidden area" can be programmed on the map to prevent the AIV from entering an area based on the state of a discrete input. If this input is set from another vehicle, such as a forklift, while it is in that area, then the AIV will not be allowed to enter that area.

Passing Lanes

Since the LD Platform Cart Transporter technology does not use fixed tracks to guide the AIVs, the concepts of passing lanes and human safety areas are not relevant.

2.4 Environment

General Environmental Conditions

It is the end-user's responsibility to ensure that the operating environment of the platform remains safe for the platform. If there are areas that are not safe for the platform to travel in, those areas should be physically blocked off so that the platform's scanning laser will detect the barriers, and the platform will not attempt to drive there. These areas can also be blocked off with forbidden zones in the MobilePlanner software, but that should be in addition to physical barriers.

Public Access

The LD Platform Cart Transporter is designed for operating in indoor industrial or professional environments. It must be deployed in a manner that takes into account potential risks to personnel and equipment. The product is not intended for use in uncontrolled areas without risk analysis, for example, areas open to general public access. Use in such areas may require deployment of additional safety measures.

Clearance

The LD Platform Cart Transporter is designed to operate in an environment that is generally level and has no doors or other restricted areas too narrow for the platform and cart. It is the user's responsibility to ensure that adequate clearance is maintained on each side of the AIV, so that a person cannot get trapped between the AIV and a wall or other fixed object. You should consult the applicable standards for your area. An exception to side clearance can exist at pickup and dropoff locations where the AIV must get close to conveyors or other fixed objects.

The primary direction of travel of the LD Platform Cart Transporter is forward. When the transporter is turning in place, with no forward movement, the detection of an obstacle in its path of rotation will not trigger an E-Stop.

**CAUTION: PERSONAL INJURY RISK**

Personnel who work with or around the transporter should not stand close to the transporter when it is turning in place (with no forward motion).

Obstacles

If the LD Platform Cart Transporter will be entering high-traffic areas, the user must take appropriate precautions to alert people in those areas that an AIV might enter. If the traffic consists of other machines, the user must adjust the AIV's and/or the other machine's parameters to reduce the risk of a collision.

Safety Scanning Laser Emergency Stop

If an obstacle enters the transporter's immediate path, the safety scanning laser will trigger an emergency stop. After the transporter has come to a complete stop, it will wait a minimum of two seconds before resuming commanded motion, with no human intervention necessary.

- If the obstacle is still in the transporter's path, it will first attempt to safely path plan and maneuver around the obstacle, if there is adequate room.
- If the transporter can't simply maneuver around the obstacle, it will search for another path to reach its goal.

If it can't find another path, it will wait for human intervention.

Safety System Overspeed Faults

A CPLD Channel 1 or 2 fault, is a system fault, reported by independent safety system to the firmware controlling the robot. A fault signal from the safety system, indicates that the robot is operating outside of the defined boundaries of safety standards EN1525/ANSI B56.5.

Both referenced standards state, that the speed of motion in directions not covered by the operator detection devices, reverse direction for the LD Platform, must be limited to <300 mm/s.

If an LD Platform is operated in a manner that exceeds this reverse speed limit, the safety system will generate and report a fault signal. In normal, autonomous operation, this condition triggers motion controllers to execute a controlled stop. However, if motion is disabled (E-Stop button is pressed) and the brake release is overridden, the safety system cannot stop the LD Platform since power to the motors has already been cut off. Once the fault condition is resolved, the safety system will stop reporting safety fault to the motion controllers, and the normal start-up process will initiate.

Following table displays overspeed fault conditions.

NOTE: The motion settings such as AbsoluteTransVelMax, that limit maximum allowable velocities in the robot software (ARAM), have no effect on the safety system.

Table 2-2. Overspeed Limits for Different LD Models

Model	Gear Ratio	Forward Limit (mm/s) ^{i,ii}	Reverse Limit (mm/s) ⁱ
LD-105CT	40:1	1575	225
LD-130CT	60:1	1050	150

ⁱ These values are approximate and represent the upper limit. Maximum speeds should be set to at least 30-50 mm/s below these values, to prevent erroneous safety overspeed faults.

ⁱⁱ The forward limits indicate where the safety system will report a fault. These speeds may not be achievable by the robot under its own power. The max forward speed, should always be set to the defined maximum (or lower) speed, found in the default configuration shipped with the robot.

2.5 Intended and Non-intended Use

Intended Use

The LD Platform Cart Transporter is designed for operating in indoor industrial or professional environments. It must be deployed in a manner that takes into account potential risks to personnel and equipment. The product is not intended for use in uncontrolled areas without risk analysis, for example, areas open to general public access. Use in such areas may require deployment of additional safety measures.

Guidelines for safe use:

- Clean, dry floors — floors that are regularly swept, and routinely kept free of debris and liquids.

IMPORTANT: Since the robot is not water proof (IP20), floors must be kept relatively dry, as any dampness can cause the wheels to slip. This can cause problems for braking as well as navigation. Refer to 13849-2 for instructions on how to test the robot in non-standard environments.

- Temperature — 5 to 40°C (41 to 104°F), with a recommended humidity range of 5% to 95%, non-condensing.

Non-Intended Use

The LD Platform Cart Transporter is not intended for use in any of the following situations:

- In hazardous (explosive) atmospheres
- Uncontrolled areas, for example, areas open to general public access

Application in such areas may require deployment of additional safety measures, and risk analysis

LD Platform Cart Transporters are designed for operating in industrial or professional environments. They must be deployed in a manner that takes into account potential risks to personnel and equipment.

- In the presence of ionizing or non-ionizing radiation
- In life-support systems
- In residential installations
- Where the equipment will be subject to extremes of heat or humidity
- In mobile, portable, marine, or aircraft systems

NOTE: The gyroscope used to assist in navigation in LD Platform Cart Transporters requires a stationary environment for optimum accuracy. Therefore, we do not recommend them for use on a ship, train, aircraft, or other moving environment.

IMPORTANT: The instructions for operation, installation, and maintenance given in this guide and the AIV user's guide must be strictly observed.

Non-intended use of LD platforms can:

- Cause injury to personnel
- Damage the platform or other equipment
- Reduce system reliability and performance

The body of the AIV must not come into contact with liquids. The drive wheels can tolerate damp floors, but the body of the AIV must remain dry.

If there is any doubt concerning the application, ask your local Omron support to determine if it is an intended use or not.

Platform Modifications

If the user or integrator makes any changes to the LD Platform Cart Transporter or cart, it is their responsibility to ensure that there are no sharp edges, corners, or protrusions.

Note that any change to the platform or cart can lead to loss in safety or functionality. It is the responsibility of the user or integrator to ensure that all safety features are operational after modifications.

2.6 Battery Safety



CAUTION: BATTERY DAMAGE RISK

Immediately charge the battery to a full charge upon receipt to avoid the risk of discharging the battery below a usable state, which would require battery replacement.

Effective April 1, 2016, IATA regulations require that air-shipped lithium ion batteries (UN 3480, PI 965) must be transported at a state of charge not exceeding 30%. You should charge the battery completely as soon as you receive it.

NOTE: If the battery was not sent by air, it may be fully-charged.

- Store batteries upright (in an environment with relative humidity less than 70%) at:
 - One month: +5 to 45°C (41 to 113°F)
 - One year: 20 to 25°C (68 to 77°F)
- Never expose the battery to water. If the battery is leaking, submerge it in mineral oil and contact your local Omron support.
- In case of a fire, use a type D extinguisher: foam, dry chemical, or CO₂.

2.7 Additional Safety Information

Accidental Cart Separation

In the unlikely event that the cart becomes unlatched from the platform while in motion, the brakes are designed to stop the cart within six feet.

Mobile Robot LD Safety Guide

Your local Omron support provides other sources for more safety information:

The Mobile Robot LD Safety Guide provides detailed information on safety for LD Platforms. It also gives resources for information on relevant standards. It ships with each LD Platform.

2.8 Disposal



Dispose of in accordance with applicable regulations.



Customers can contribute to resource conservation and protecting the environment by the proper disposal of WEEE (Waste Electronics and Electrical Equipment). All electrical and electronic products should be disposed of separately from the municipal waste system via designated collection facilities. For information about disposal of your old equipment, contact your local Omron support.

Chapter 3: Setup

Overview

In general, setup is the physical preparation of the platform and cart, and physically marking parking goal locations on your facility floor. Marking the parking goals on the floor is for human use. An LD Platform Cart Transporter will not use those markings, although we recommend you mark them in any case to prevent someone from placing something there that would prevent a cart from being parked.

Setup also includes generating a map of the workspace and configuring the AIV with the MobilePlanner software to perform useful tasks.

Tasks

This overview covers the LD Platform Cart Transporter starter kit, which includes the LD Platform Cart Transporter with all components needed for use including a cart, a docking station, and the software needed for navigation.

- Install the battery in the platform. See *Installing the Battery* on page 45.
- Fully charge the battery, either outside of or inside the platform.
- Set up the wireless Ethernet for the platform. See *Configuration* on page 61.
- Install the docking station. See *Installing the Docking Station* on page 49.
- Install the cart's manual brake-release cable and lever.
- Design, build, and install a payload structure, to suit your application. See *Payloads* on page 75.

This is the most involved task in getting your AIV working the way you want.

- Configure the AIV for your environment, so it can perform useful tasks.

This includes generating the map that the platform will use for its navigation. This procedure and parameter configuration is covered in the *Mobile Robot Software Suite User's Guide*.

- Mark the location and orientation of the goals where the cart can be parked. This allows a person to place a cart where the transporter can find it.

It will also help keep someone from putting something other than a cart in that area, which could prevent a cart from being parked in that location.

- Configure the MobilePlanner software, so a transporter can pick up and drop off carts.

This includes modifying the map that the transporter uses for its navigation. The configuration is covered in the *Mobile Robot Software Suite User's Guide*.

3.1 Transport and Storage

Use a forklift, pallet jack, or similar device to move the shipping containers.

The containers must always be shipped and stored in an upright position in a clean, dry area that is free from condensation. Do not lay the containers on their sides or any other non-upright position.

LD Platform Cart Transporter

The LD Platform Cart Transporter system, which includes a cart, is shipped in one crate, along with the docking station, joystick, and all components except for the battery.

The system must be shipped and stored in a temperature-controlled environment, from -20 to 60°C (-4 to 140°F). The recommended humidity range is 5% to 95%, non-condensing. It should be shipped and stored in the supplied shipping crate, which is designed to prevent damage from normal shock and vibration. You should protect the crate from excessive shock and vibration.

The transporter alone weighs 81 kg (179 lb).

The crate for the transporter measures 1257 x 1149 x 1645 mm (49.50 x 45.25 x 64.75 inches), and weighs 129 kg (284 lb). The weight, as shipped, is 230 kg (507 lb).

Battery

NOTE: If you purchased spare batteries, this section applies to them, also.

The battery is shipped in a separate carton, not inside the platform or platform crate.

Storage Requirements

If the battery needs to be stored, the manufacturer recommends:

- +5 to 45°C (41 to 113°F) for up to a month
- 20 to 25°C (68 to 77°F) for up to a year

The battery should start storage fully-charged and upright, in a dry location. If storing the battery for an extended period, recharge the battery periodically to avoid total discharge, which would damage the battery. Fully recharging a battery every six months is sufficient to keep it charged enough to avoid damage.

Maintenance

Every six months:

- Inspect the battery for damage or leaks.
- Place the battery on a charger and allow to fully balance (battery shows all solid LEDs when fully balanced). Fully recharging a battery every six months is sufficient to keep it charged enough to avoid damage.

Standalone Cart

Carts can be purchased as an option, if you need more carts than transporters.

The cart box measures 1092 x 635 x 711 mm (43 x 25 x 28 inches). Weights are listed in the following table.

Table 3-1. Item Weights

Item	Weight
Cart	22.7 kg (50 lb)
Cart and Box	28 kg (62 lb)
Cart, Box, and Pallet	44.5 kg (98 lb)

Each cart comes with caster brakes, which require the installation of a brake-release lever. See *Installing the Cart Brake Release* on page 54.

3.2 Before Unpacking

Carefully inspect all shipping containers for evidence of damage during transit. If any damage is indicated, request that the carrier's agent be present at the time the containers are unpacked.

3.3 Unpacking

Before signing the carrier's delivery sheet, compare the actual items received (not just the packing slip) with your equipment purchase order. Verify that all items are present and that the shipment is correct and free of visible damage.

- If the items received do not match the packing slip, or are damaged, do not sign the receipt.
- If the items received do not match your order, please contact your local Omron support immediately.

Retain the containers and packing materials. These items may be necessary to settle claims or, at a later date, to relocate the equipment.

A complete LD Platform Cart Transporter will come in two packages:

- The battery is shipped in a separate cardboard carton.
- The transporter and cart are shipped in a wooden crate.

This includes the HMI post with the side laser support tubes.

This also includes the joystick, docking station, as well as miscellaneous cords all in a cardboard carton inside the transporter crate.

NOTE: If extra accessories are ordered, they will be shipped separately.

Battery

The battery is shipped separately from the transporter. Locate the box that contains the battery before continuing. Refer to the following figure.



Figure 3-1. Battery Shipping Container

The battery box measures 311 x 540 x 457 mm (12.25 x 21.25 x 18 inches).

NOTE: The battery weighs 19 kg (42 lbs). There are recesses at the front and the back of the battery, to aid in lifting it.

LD Platform Cart Transporter




Figure 3-2. Cart and LD Platform Cart Transporter in Crate

The transporter crate measures 1257 x 1149 x 1645 mm (49.50 x 45.25 x 64.75 inches).

Removing the Front Panel

The front panel of the transporter crate doubles as a ramp, for rolling the platform off of the crate base.

1. Release the latches that hold the front panel to the crate.

There are four spring-loaded latches.



Figure 3-3. Spring-loaded Latch

2. Remove the front panel, and set it aside.

This will be used as a ramp, to roll the platform off of the crate base.

Removing the Upper Body of the Crate

1. There are six lag bolts and washers around the base of the crate, two in the rear and two on each side. Remove all six lag bolts and washers.



Figure 3-4. Crate Lag Bolts

2. Slide the upper body of the crate off of the base.

Take care as you slide it over the HMI post, watching the clearance between the crate and the HMI post components.

The platform will still be held securely by the base of the crate.

**CAUTION: PERSONAL INJURY OR PROPERTY DAMAGE RISK**

Due to the weight and size of the crate upper body, and the potential to damage the platform during this step, two people should work together to remove it.

Removing the Cart

The cart is secured under a wooden panel and a cardboard box.

1. Loosen the restraining strap that is around the cardboard box.
2. Remove the cardboard box.

This contains the dock and the joystick, as well as miscellaneous cords.

If accessories, such as call boxes, are ordered, they will be shipped separately.

3. Release the two spring-loaded latches on either side of the panel that is securing the cart.




Figure 3-5. Cart Panel Latches

4. Remove the panel and the straps off the top of the cart. Then remove the cart itself.

**CAUTION: PERSONAL INJURY RISK**

Due to the weight of the cart, two people should work together to remove it from the crate.

Removing the Crate Braces

1. Remove the top brace by releasing the four spring-loaded latches, two on either side of the brace.
2. Remove the front brace by releasing the two spring-loaded latches, one on either side of the brace.




Figure 3-6. Crate Braces

Repacking for Relocation

If the LD Platform Cart Transporter or other equipment needs to be relocated, reverse the steps in the installation procedures in this chapter. Reuse the original packing crates and materials and follow all safety notes used for installation. Improper packing for shipment will void your warranty.

The LD Platform Cart Transporter must always be shipped in an upright orientation.

3.4 Setting Up an LD Platform Cart Transporter

The LD Platform Cart Transporter is shipped with the HMI post installed. This includes the Operator panel at the top of the HMI post. You will have to:

- Roll the transporter off of the crate, down the ramp
This will be rolling on the casters, not the drive wheels.
- Remove the pins holding the drive wheels up
- Install the battery
- Install the dock, for charging the transporter's battery
This should have already been removed from the crate.
- Set up your wireless system
This is covered in Settings and Configuration on page 61.

Rolling the LD Platform Cart Transporter off of the Crate Base

1. Install the crate front onto the crate base, to serve as a ramp.

There are two hanger bolts that stick up out of the front of the crate base. These fit into two holes in the end of the ramp. Orient the ramp as shown in Figure 3-7. to ensure there is a smooth transition between the ramp and the ground.

2. Roll the transporter off of the crate base and down the ramp.



Figure 3-7. LD Platform Cart Transporter on Crate Base, with Ramp

3. Remove the two wheel pins that held the wheels up during transit.

The wheels are pinned up to protect the motors and drives. When you receive your LD Platform Cart Transporter, the drive wheels will not touch the ground until you remove the wheel pins. The wheel pin hole is shown in the following figure.




Figure 3-8. Wheel Pin Hole Location

For each side of the platform:

- a. Remove the side cover a small distance from the platform. Refer to Removing Covers on page 159.

The light disc PCA cable will still be attached.

- b. Disconnect the cable from the light disc PCA, so the side cover can be moved completely away from the platform.

This will fully expose the wheel and tire.

- c. Lift the wheel slightly to relieve pressure on the pin.
- d. Remove the pin by pulling the ring that is attached.

These pins can be used for later service of the entire drive assemblies.



Figure 3-9. Wheel Pin

- e. Lower the wheel to the floor.

The wheels are spring-loaded, and the wheel brakes will be on.

- f. Put the side cover next to the platform, and attach the light disc cable to the light disc PCA.
- g. Reinstall the side cover.

Installing the Battery

Your platform battery comes with less than 30% charge, to comply with air-shipping regulations. It should be charged as soon as possible, to a full charge.

NOTE: Air shipping regulations require that the transporter be shipped without the battery installed.

Removing the Battery Cover

Accessing the battery compartment requires removing the platform's rear cover. This is held in place with magnets.



CAUTION: PINCH RISK

The magnets holding the cover in place are strong enough to pinch you if you are not careful.

No tools are needed for either the removal or installation of the battery cover.

NOTE: After removing the cover, place it inner-side down, so the outer surface doesn't get scratched.



Figure 3-10. Pulling the Bottom of the Rear Cover Out




Figure 3-11. Lowering the Rear Cover

Refer to Removing and Installing LD Platform Cart Transporter Covers in the Maintenance section for cover removal and installation.

1. Remove the inner rear platform cover.
 - a. Pull the bottom of the cover away from the platform chassis.
This is easiest if you grip it with two hands, toward the center.
 - b. Lower the cover down, so its top tab clears the rear outer cover.
2. Unlatch and open the battery compartment door, at the back of the platform.

The battery compartment door is capable of being locked. You may need to unlock it.

3. Lift and slide the new battery into the platform body.

The battery weighs 19 kg (42 lbs).

There are recesses at the front and the back of the battery, to aid in lifting it.



Figure 3-12. Battery Recesses, for Gripping

The battery is designed to be lifted and replaced by one person, using one hand in each of the grips, as shown in the following figure.



Figure 3-13. Lifting the Battery

The connectors for power and data go toward the rear of the platform.

4. Attach the battery power and data cables to the connectors at the rear of the battery.




Figure 3-14. Battery Cable Connectors, (A) Power and (B) Data

5. Close the battery compartment door to secure the battery in place.

The battery compartment is designed to hold the battery tightly, so that it will not move within the compartment, once the door is closed.

6. Reinstall the inner rear platform cover.

Installing the Docking Station

The automated docking station can be used for either manual or automated charging of your LD Platform Cart Transporter's battery.

The docking station sits on the floor. It can be attached to a wall with the wall bracket, attached directly to the floor with screws through its base, or it can sit stand-alone on the floor with the floor plate, all of which will keep the docking station from moving when the transporter docks. Each docking station comes with a wall bracket and floor plate.

NOTE: It is very important that the docking station be mounted with one of these methods, or the transporter will simply move the docking station when it tries to dock, rather than docking successfully.

Regardless of mounting method:

- Locate the docking station near an AC outlet with 1-2 m (3.25-6.5 ft) of clear space in front to ease the transporter's maneuvers onto the docking station.
- When docked, the rear-facing laser extends almost 5 inches beyond the back of the docking station. Ensure that you leave enough free space behind the back of the docking station to allow clearance for this.

The wall-mount bracket provides enough room for this.

- The top of the docking station foot is spring-loaded, and lifts off of the bottom of the foot slightly to accommodate variations in the floor surface. The weight of the transporter will push the top of the foot down.

Requirements

- 100-240 VAC, 50/60 Hz, 8 A

The station's power converter automatically detects the source voltage.

- Ambient operating temperature: 5 to 40°C (41 to 104°F)
- 5% to 95% humidity, non-condensing

Wall Bracket Mount

NOTE: This is the recommended method for mounting the docking station.

1. Attach the docking station mounting bracket to a wall, with the bottom edge of the bracket 98±20 mm above the floor, using user-supplied anchors and screws. There is leeway, so you can adjust the height a little bit.

Refer to the following figure:




Figure 3-15. Docking Station, Wall Mount Bracket Detail, (A) Through Hole (units are in mm)

2. Screw the two shoulder bolts, each with a washer, into the rear of the docking station. The shoulder bolts are M5 x 4, stainless steel. Their locations are shown in the following figure. Tighten to 9 N·m (80 in-lb).



Figure 3-16. Rear View of Docking Station with Shoulder Bolts

3. Lower the docking station down, so the two shoulder bolts on the back of the docking station slide into the bracket, to secure the docking station to the wall.

Floor-mount, without Floor Plate

NOTE: Because this method permanently attaches the dock to the floor, it may be subject to building code regulations. It is the user's responsibility to verify that the installation is in compliance with local regulations.

Screw the base of the docking station directly to the floor, using three user-supplied screws. For dimensions of the available holes in the base, refer to Figure 3-15. We recommend M5 self-tapping or M4 drywall screws for this.

Floor-mount, with Floor Plate

This mounting method uses the floor plate. The floor plate is not shipped attached to the docking station, so you must attach it for this type of mount. It will be in the crate with the docking

station.

Attaching the Floor Plate

Refer to the following figures.

1. Tip the docking station onto its back, so you can access the underside.
2. Remove the two lowest screws (M4 x 12 flat-head), if present.

In the following figure, these screws are circled. The location of the third screw hole is also circled.

3. Attach the floor plate to the base of the docking station with three M4 x 12 flat-head stainless steel screws.

The floor plate comes with three screws, so you will have two spares.

The docking station and floor plate do not need to be attached to the floor, as the weight of the platform on the floor plate will keep the docking station from moving.



Figure 3-17. Underside of Docking Station Foot, Showing Screw Locations

NOTE: These are the three locations for the M4 x 12 flat-head screws. Two are already in place, and need to be removed before attaching the plate.




Figure 3-18. Docking Station, Mounted on Floor Plate




Figure 3-19. Docking Station Floor Plate Dimensions (units are in mm)

Power On

Install the power cord and turn the power switch to ON. The power switch is next to the power plug. The blue power LED indicator should light.

Docking Station Contact Adjustment

The contacts on the docking station have five height settings. The station is shipped with the height in the middle setting, which should be correct in most cases. The height can be changed by tilting the station enough to see the bottom of the base, making the adjustment accessible.

Additional Information: Squeeze and keep the docking station foot against the bottom of the docking station to make this adjustment easier.

Adjust the height of the contacts by using the pull-knob on the bottom of the dock. The height changes by 4 mm (0.15 inch) for each notch. See the following figure.

The height of the contacts should be set so that the roller is high enough to stay in contact with the platform as it is docking, but low enough so that the bi-level of the roller guides the paddle under the platform.




Figure 3-20. Docking Station Contact Adjusting Pull-Knob

3.5 Installing the Cart Brake Release

The two rear casters of the cart have brakes, which push a blunt pin against the caster rolling surface to prevent the cart from rolling when it is parked on a floor that is not perfectly level.



Figure 3-21. Cart Caster Brake, Showing Spring and Pin

To allow an Operator to release the cart brakes when there is no cart LD Platform Cart Transporter present, each cart comes with a brake-release cable and lever, similar to a bicycle hand brake, that releases the cart brakes when squeezed.

NOTE: The cart brake-release mechanism is actuated by the transporter when it couples with the cart, so the cart will roll freely with the transporter. This part of the brake release does not requires any user setup or adjustment.

Installation

The cart brake cable is attached on one end to the cart brake-release mechanism, and outfitted on the other end with a bicycle-style brake lever, to release the cart's brakes and allow an Operator to move the cart manually. It is up to the user to mount the brake-release lever at some location on the cart, and route the brake-release cable from the brake-release lever to the actuator. The brake-release lever comes with a 1524 mm (60 inches) cable. The lever has a clamp the fits a 22 mm (7/8 inch) tube.



Figure 3-22. Brake-release Lever



CAUTION: PERSONAL INJURY RISK

It is important that the brake-release handle be mounted in an ergonomically-suitable location, so an Operator can repetitively release the brakes without risking injury.

The actual mounting location and procedure for the brake-release handle are not covered here due to the variability that is possible in cart structure designs. Ensure that no part of the cart brake-release cable bends more than a 76 mm (3 inches) radius.

There is a 6.4 mm (0.25 inch) horizontal hole through the rear horizontal tube of the cart. See the following two figures.



Figure 3-23. Thru-hole for Brake-release Cable, (A) 6 mm diameter (0.25 in.) pass-through hole for brake cable, through rear frame tube




Figure 3-24. Thru-holes for Brake-release Cable, Plate Removed

Callout	Description	Callout	Description
A	Route brake-release cable up to brake lever	C	Secure brake-release cable to saddle tie
B	6 mm diameter (0.25 in.) hole through rear tube wall		

After the brake-release lever has been mounted on the cart payload:

1. Push the free end of the lever cable through the hole in the cart's upper-rear horizontal tube.




Figure 3-25. Internal Brake-Release Mechanism

Callout	Description	Callout	Description
A	Right Brake Cable	F	Actuator Bar
B	Right Brake Adjust	G	Actuator Bar Hard Stop
C	Lever Cable	H	Left Brake Cable
D	Pulley	I	Left Brake Adjust
E	Lever Cable Anchor	K	Lever Cable Clamp

2. Route the cable to the lever cable anchor.
3. Attach the actuator end of the cable to the lever cable anchor.

4. Run the inner wire of the cable around the pulley, through the bushing in the actuator bar, and through the lever cable clamp.
5. Pull the inner wire tight enough to remove slack, and tighten the lever cable clamp on it.
6. Cut off the excess inner wire, leaving a small amount protruding past the clamp.
7. Make a service loop of any excess lever cable, at least 152 mm (6 inches) in diameter.
8. Attach the lever cable housing to the saddle tie. See Figure 3-24.

Adjustment

The brake lever cable needs to be adjusted so there is no excess slack, but so the brakes are engaged when the lever is not being actuated. The two caster brake cables will be adjusted at the factory.

Brake Lever Cable

The brake lever cable should be adjusted at the lever cable clamp, shown in the preceding figure. There should be just enough slack so the actuator bar touches its hard stop.

Caster Cables

These should be adjusted correctly from the factory. If any adjustment is needed, refer to the preceding figure for the adjustment location. The brake pins should be able to go down as far as the caster surface allows, without any slack. The jam nuts on the two brake adjustments should be installed using a threadlocker.

Actuator Bar Hard Stop

After the caster cables are adjusted correctly, ensure that the actuator bar just touches its hard stop. This will keep the actuator bar in position if you have to adjust the lever cable.

Chapter 4: Configuration

The LD Platform Cart Transporter comes with firmware and on-board software installed.

Configuration of an LD Platform Cart Transporter is done using the MobilePlanner software. Configuration includes generation of the map that the AIV will use for navigation. The cart parking goals need to be added to that map. This manual only provides an overview of that process, which is covered in detail in the *Mobile Robot Software Suite User's Guide*.

IMPORTANT: The MobilePlanner dongle, which contains the license for running the software, should be locked up when not in use, to prevent unauthorized modifications to your system configuration. Turn off the software when not in use.

Other setup, mostly for communication, is handled by the SetNetGo OS, which is accessed through the MobilePlanner software. It can also be accessed through a direct connection, so your IT support can set up your wireless without needing the MobilePlanner license.

The transporter navigates using a map, generated with the MobilePlanner software. The operation of this software, as well as the downloading of the resultant map to the platform, is covered in the *Mobile Robot Software Suite User's Guide*.

NOTE: The map must be generated and downloaded to the platform before you can perform the steps covered in this chapter.

By default, the LD Platform Core, safety scanning laser, and some auxiliary power start automatically when you press ON.

4.1 Settings and Configuration

Maintenance Ethernet Connection

To prepare your AIV for autonomous mobile operation, attach a PC to the platform's Maintenance Ethernet port, and connect with the SetNetGo OS through the MobilePlanner SetNetGo interface.

If you do not have wireless yet, you can connect MobilePlanner through the wired Ethernet port (Maintenance LAN) and set up the wireless network later.




Figure 4-1. (A) PC, (B) Cat 5 Ethernet, and (C) Maintenance Access Panel

The LD Platform core is preset and tested on a Class-C network (netmask for all ports 255.255.255.0). The Maintenance Ethernet port is set to IP address 1.2.3.4 and the wireless IP comes set with an AP-based ("managed") SSID of "Wireless Network", unsecured. Consult with your network systems administrator before modifying these network details through the SetNetGo OS.

The User LAN port is set to IP address 10.10.10.10.

Refer to the *Mobile Robot Software Suite User's Guide*.

The Maintenance Ethernet port is on the left side of the platform, under the small access panel at the upper-right corner of the platform. (The joystick port is also there.) The access panel is held in place with a push-push latch, and retained by a lanyard. See Figure 10-3. This is internally connected to the Ethernet port located on the rear side of the LD Platform core in the payload bay.

The Maintenance Ethernet port is permanently set to IP address 1.2.3.4, with a netmask of 255.255.255.0, for direct, wired access to the onboard systems. Accordingly, when accessing the port, manually set the offboard computer's Ethernet to an IP 1.2.3.x, where x is any number 1 through 254 except 4, and with a netmask of 255.255.255.0. No special DNS or gateway settings are needed.

Attach a pass-through or cross-over CAT5 (or better) Ethernet cable between the PC and the Maintenance Ethernet port of the platform. The platform Ethernet is Auto-MDIX, and will detect the type of cable you are using.

Start the Network Connections: Local Area Connection dialog for the ETH 0 Ethernet port:

(Windows 7) **Start > Settings > Network Connections > Local Area Connection**

(Windows 10) **Start > Settings > Network and Internet > Change Adaptor Options > Local Area Connection**

Select **Properties**, and, from its dialog, scroll to and double-click the **Internet Protocol (TCP/IP or TCP/IPv4)** option. In the Internet Protocol (TCP/IP) Properties dialog, click both 'Use the following...' associated radio buttons to enable them, and then type in the IP and netmask values.

Setting Up Wireless Ethernet

The SetNetGo OS is used to configure the platform wireless Ethernet, among other things. Refer to the *Mobile Robot Software Suite User's Guide* for details.

NOTE: Although an LD Platform Cart Transporter is capable of working without wireless Ethernet if there are no other AIVs that it needs to know about (and to avoid), that is the exception. In most cases, wireless Ethernet will be needed.

NOTE: For all of the following settings, work with your IT group to verify the correct IP, radio, and security settings.

The following applies to the wireless Ethernet supported by the platform.

The SetNetGo OS is used to configure the wireless Ethernet, among other things. Refer to the *Mobile Robot Software Suite User's Guide* for details.

Access the SetNetGo OS through the MobilePlanner software:

MobilePlanner > SetNetGo > Network

NOTE: It is also possible to connect directly to the SetNetGo OS on a platform through a web browser. The main intent of this is to allow your IT support to set up the network for you, without using MobilePlanner, which requires a license.

IP Address, Netmask, Gateway, DNS1

Choose Static (DHCP is not recommended), and fill in the IP address, netmask, gateway, and DNS1, as supplied by your network administrator.

NOTE: The following settings have to be provided by your IT department.

Radio Settings

- SSID (e.g. AGV)
Fill in the appropriate wireless SSID for your wireless network.
The SSID is case sensitive.
- Mode
Managed/STA, Ad-Hoc, or Master/AP
- Radio Mode
Auto, 802.11a, 802.11b, 802.11g
- Channel Set
- Wireless Watchdog IP Address
- Wireless Watchdog Max Count
0 disables this.

Security Settings

Encryption:

- Disabled
- WEP 64-bit
- WEP 128-bit
- TKIP/RC4
- CCMP/AES
- TKIP/CCMP/AES

Authentication:

- OPEN
- WPA-PSK
- WPA2-PSK

WEP

- WEP Key Number (Key 1 - Key 4)
- WEP Keys

WPA/WPA2-PSK

- PSK
- PSK-Type (Passphrase or Raw Hex)

Click **Apply** for your changes to take effect.

Wireless Coverage

The AIV must have wireless coverage for multi-AIV installations, or in areas where you wish to send new commands to or receive status updates from the AIV.

Ensure that, in such cases, you have adequate wireless coverage. Because of the variation possible in different environments, we don't specify what components or techniques should be used to obtain this coverage.

We suggest that you conduct a comprehensive site survey to ensure adequate wireless coverage. You can test the coverage of your wireless setup by trying to ping it from various locations.

>= -40 dBm is the ideal WiFi signal strength, -60 dBm is the recommended minimum.

Bandwidth Considerations

The typical bandwidth in a fleet will average about 50 Kbps/AIV. This would increase if the AIV is connected to the Enterprise Manager, and is actively viewed by MobilePlanner. This number can increase or decrease depending on the types of commands and debugging tools that are enabled in MobilePlanner. In any case, the bandwidth is not likely to exceed 500 Kbps per AIV (0.5 Mbps).

0.5 Mbps per AIV would easily fit within the capabilities of access points (≥ 54 Mbps). If you have multiple access points, this number becomes even less of a concern.

Also, other factors will affect the bandwidth requirements, such as if the AIV supports a camera on top and streams the video through the AIV's WiFi interface. Based on such possibilities, the bandwidth usage will vary by application.

4.2 Mapping

Mapping Overview

There are many options for configuring and tuning your LD Platform Cart Transporter to best suit your application.

In order to have your transporter perform autonomous mobile activities, you need to make a map of its operating space. Configuration includes generation of the map that the transporter will use for navigation. The cart parking goals need to be added to that map. Use the MobilePlanner application to make the map. This manual only provides an overview of that process, which is covered in detail in the *Mobile Robot Software Suite User's Guide*.

Maps may contain a variety of virtual elements which act to modify the behavior of an AIV. Virtual elements include forbidden lines and areas, speed zones, preferred-direction zones, and more, all working to help you configure your workspace for efficient and safe performance of your mobile application. You can also create your own virtual elements for application-specific AIV-workspace interactions.

Maps contain a variety of goals, routes, and tasks that comprise the destinations and activities of the AIV in the workspace. There needs to be a goal at every location where you want the transporter to be able to pick up or drop off a cart. Make sure that the goal orientations leave room for the platform to maneuver.

Mapping Tasks

- Install the automated docking station before you create a map file. Its distinctive front angle will be helpful in locating it on the map.
- Drive the platform with the joystick to make a floor plan scan. We recommend that you drive it to and position it onto its automated docking station to prepare for the next steps.
- Load that floor plan scan into MobilePlanner, on your PC, to make and edit the map.
- Add goals and docks to your map. In particular, refer to:

**Working With Map Files > Editing a Map File >
Using the Drawing Tools > Adding Goals and Docks**

in the *Mobile Robot Software Suite User's Guide*.

- Transfer the working map to the Enterprise Manager, or back to the platform, if you have only one platform, to perform autonomous mobile actions.

The Enterprise Manager will automatically download the new map to each AIV in your fleet as soon the AIV becomes idle.

- If you have multiple, separate working spaces, which will each require their own map,

you can save map collections and deploy your platform in any of your working spaces by selecting the appropriate map file.

Setting Up Cart-Parking Goals

Any location where you want a cart to be picked up or dropped off needs to have a corresponding goal on the map. Pay special attention to the direction of the goals, as the transporter may need extra room to maneuver into the correct position for coupling.

Marking Cart-Parking Goals on Floor

The purpose of marking the parking goals on your floor is so that a human being knows where to leave a cart, so that the transporter will find it and be able to couple with it.

Even if people will never be moving carts, this step is recommended, so that someone doesn't place other items where a cart needs to be parked.

If people will be moving carts, make sure that your markings include the direction of the goal, so the transporter will be approaching from the correct direction.

The easiest way to accurately mark the goals where a cart may be parked is to send the transporter to each cart-parking goal, and, while the transporter is at the goal, put down tape markings that include the size of the cart, as well as the transporter's orientation. The transporter will always approach the goal from the same direction, so the cart needs to be oriented correctly.

4.3 Configuring a Touchscreen

You configure the touchscreen's appearance and behavior with the MobilePlanner software. The tasks include setting the mode to use, setting up goals for relocalization, and specifying a custom screen logo and the language to be used for the display.

Touchscreen Ethernet Setup

The touchscreen plugs into the User LAN port on the platform's core.

NOTE: After making and saving changes within User LAN Ethernet Settings, the platform has to be power-cycled for those changes to take effect. If the only change is to enable DHCP, then the platform does not have to be power-cycled.

In the MobilePlanner software, select:

MobilePlanner > SetNetGo

Network > User LAN Ethernet

Ensure that:

- the IP address subnet doesn't conflict with the Wireless Ethernet IP subnet
- Interface mode is set to Accessory
- DHCP Server for Accessories is set to Enable
- DHCP IP Range is large enough to provide IP addresses for all connected devices




Figure 4-2. Accessory and DHCP Server for Accessories Enabled

Operating Modes

Specify the touchscreen mode: either Choose Dropoff or Patrol Route.

- Choose Dropoff mode allows the Operator to input the next dropoff goals.
- Patrol Route mode simply drives around a specific route. The AIV will have goals that it stops at, but the Operator will not be able to alter the order of those goals.

For Choose Dropoff, you specify how many dropoff buttons there will be, and how each button is labeled, as well as the goal on the AIV's map that gets associated with each button.

For Patrol Route, you specify the name of the route and whether to start the patrol on bootup. The route will include whatever goals the AIV will stop at, and how long it will wait at each specific goal.

These parameters are accessed from:

MobilePlanner > Config, then Robot Interface > Touchscreen

Select either Choose Dropoff or Patrol Route with the **Pages > MainPage** parameter, which has a dropdown selection box.

Choose Dropoff Mode

The following parameters only apply to the Choose Dropoff mode.

Dropoff Priority

This is accessed under **Pages > ChooseDropoffPage**.

You can enable high-priority dropoffs, which will be serviced before normal-priority dropoffs. The Operator can specify that a goal is high-priority when it is being selected for the upcoming dropoff.

AllowHighPriorityDropoffs

This allows some dropoffs to be specified as high-priority. This is enabled by default, and you can disable or re-enable it in the MobilePlanner software.

HighDropoffPriority

This is the priority assigned to any dropoff that is specified as high-priority. Higher priority jobs will be serviced before lower-priority jobs by the queuing manager. This has no effect if AllowHighPriorityDropoffs is disabled.

Dropoff Buttons

This is accessed under **Pages > ChooseDropoffPage**.

DropoffButtonCount

This specifies the total number of buttons that will be available on the touchscreen page. You can scroll the page to see other buttons, if all of the buttons cannot be displayed at once.

DropoffButtonx

There will be a DropoffButton1 through DropoffButtonx, where x = DropoffButtonCount. Each contains the two following parameters:

GoalName

This is a combo box that lists all of the goals that have been created on the map. Select the map goal to be serviced when this dropoff button is pressed.

NOTE: A goal can have a wait time associated with it, to give an Operator time to load or unload the AIV. This is configured, in the map, using the MobilePlanner software.

You can eliminate a button from the screen by making GoalName blank. The other buttons will fill in, so there will be no blank spaces in the screen.

ButtonLabel

This is the text label displayed on the dropoff button. If empty, the GoalName is displayed.

Patrol Route Mode

The following parameters only apply to the Patrol Route mode.

In this mode you need to specify the name of the Patrol Route that the AIV will patrol. The route needs to have already been set up using the MobilePlanner software. You also need to specify if the AIV will start its patrol automatically, or if it requires an Operator to press Go.

Select **Pages > PatrolRoutePage**

- In RouteName, enter the route to be patrolled.
- Check AutoStartRoute for the AIV to start its patrol as soon as the Patrol Route screen is displayed (the touchscreen has finished booting).

Localization Goals

You need to configure at least one localization goal. You can configure more if you want. A localization goal is needed to relocalize a lost AIV from the touchscreen.

Each localization goal should have:

- a heading

The AIV will need to be aligned with the heading when relocalizing.

This applies to both laser and Acuity localization.

- mapped features that don't change much

Things that get moved frequently, such as pallets, chairs, or carts do not make good mapped features, because the map will not match what the laser is seeing.

- mapped features that don't get blocked

If a mapped wall is often used for stacking boxes or storing carts, the laser may have trouble seeing the wall behind those objects.

- multiple visible lights, when using Acuity localization

The more lights the AIV can see, the better.

- a high localization score

This represents the percent of readings that the AIV currently sees that match the features on its map.


NOTE: Localization goals do not have to be dedicated to localization - they can also be used as normal goals for regular use.

In MobilePlanner, select:

Config > Robot Interface > Touchscreen

From there, use ChooseLocalizationPage to set LocalizationButtonCount to the number of localization goals you want, and then specify the GoalName and ButtonLabel for each.

4.3 Configuring a Touchscreen



The screenshot shows the 'Robot Interface' configuration window with the 'Touchscreen' section selected. The 'Parameters' tab is active, displaying a table of localization goal parameters. The table has columns for Parameter, Value, Description, Min, and Max. The parameters are grouped into sections: ChooseLocalizationPage, LocalizationButtonCount, LocalizationButton1, LocalizationButton2, LocalizationButton3, LocalizationButton4, and Style/Appearance.

Parameter	Value	Description	Min	Max
ChooseLocalizationPage		Defines the appearance of the Choose Localization Page.		
LocalizationButtonCount	4	Total number of localization buttons to create.	0	24
LocalizationButton1		A localization button.		
GoalName	BackEntrance	Map goal that serves as a localization point.		
ButtonLabel	Back Entrance	Text label that is displayed on the localization button. If empty, the GoalName is displayed.		
LocalizationButton2		A localization button.		
GoalName	Lab	Map goal that serves as a localization point.		
ButtonLabel	Eng. Lab	Text label that is displayed on the localization button. If empty, the GoalName is displayed.		
LocalizationButton3		A localization button.		
GoalName	Lobby	Map goal that serves as a localization point.		
ButtonLabel	Lobby	Text label that is displayed on the localization button. If empty, the GoalName is displayed.		
LocalizationButton4		A localization button.		
GoalName	TestStation	Map goal that serves as a localization point.		
ButtonLabel	Test Station	Text label that is displayed on the localization button. If empty, the GoalName is displayed.		
Style/Appearance		Defines the style and appearance of the Touchscreen.		

Figure 4-3. Localization Goal Parameters

Screen Logo

In MobilePlanner, select

Config > Robot Interface > Touchscreen

From there, use Style/Appearance.

A logo is displayed in the upper-left corner of the touchscreen. The default logo is Omron, as shown in the following figure.



Figure 4-4. Sample Touchscreen, with Omron Logo, in Choose Dropoff Mode

You can customize this with a logo of your choosing using the following steps:

1. Upload a PNG image file to the AIV using the MobilePlanner software:

File > Download/Upload

2. Open the Configuration window and choose:

Robot Interface > Touchscreen

3. Edit the SmallLogo parameter.
 - a. Click the file-select button to open the file chooser.
 - b. Select the newly-uploaded file.
 - c. Click Open.
4. Click Save, to save the configuration.

NOTE: If the SmallLogo field is left blank, the default Omron logo will be displayed.

NOTE: If a different version of the same file name is uploaded to the AIV, you will need to power cycle the AIV to see the change.

Screensaver

In MobilePlanner, select

Config > Robot Interface > Touchscreen

From there, use Screensaver.

If the AIV is in motion when the screensaver comes on, it will use the Busy icon, and display a status message (where it's going). If the AIV is not in motion, it will display the Available icon. The rounded rectangle, icon, and any text inside the rectangle will move around the touchscreen display area.

Screensaver Enabled

This is a checkbox that determines whether a screensaver is displayed when the touchscreen is inactive. Checking the box enables the screensaver.

TimeoutSeconds

This is the number of seconds that will elapse before the screensaver is turned on. This has no effect if the Screensaver Enabled box is not checked. The range is 1-999 s.

StayOnTouch

This is a checkbox that determines if touching the screensaver has the same effect as touching Stay. If this is checked, the AIV will stay when the screensaver is touched.

Display Language

You can select what language is used for the display from a dropdown box in the MobilePlanner software.

NOTE: Some messages from the AIV will be in English, regardless of the language set here. These include status and mode messages.

From MobilePlanner, select:

Config > Robot Interface > Language/Location

Select RobotLanguage, which has a dropdown selection box.

This parameter is not touchscreen-specific, so it may affect other displays that involve written language. As of this writing, only the touchscreen is affected. This parameter does not affect synthesized speech.

Contact Information




Figure 4-5. Help Screen, with Contact Information

Help shows installed software and contact information.

NOTE: No contact information will be displayed unless it is set up in the MobilePlanner software.

In **MobilePlanner > Config:**

- **Robot Interface > Touchscreen > ContactInformation**
- Check the ShowContactPage checkbox.
- Enter appropriate information in ContactName and the fields following it.

4.4 Acceleration, Deceleration, and Rotation Limits



CAUTION: PROPERTY DAMAGE RISK

If you change *AbsoluteMaxTransVel*, you should commission the AIV before putting it into service.

Reducing the absolute max allowable linear and rotational acceleration, deceleration, and speed will affect the size of the allowable CG envelope, but it may do so in non-obvious ways. For use-cases where the payload can't be decreased, or the CG can't be brought within the recommended limits, our Field Service department can work with your system designer to input your needs into our models.

Contact your local Omron support for details.

If your payload's center of gravity is not within the guidelines given in the Payloads chapter, you will need to adjust the Absolute Movement Maximums parameters in the MobilePlanner software.

From the MobilePlanner software, Config:

Robot Physical > Absolute Movement Maximums

Show Expert + Parameters needs to be checked to see or modify these parameters.

The first four parameters and AbsoluteMaxRotVel are not likely to have significant impact on the AIV's stability. The Accel and Decel parameters will have a major impact. In certain cases, if the payload is lopsided, the AbsoluteMaxRotVel may need to be adjusted.

The limits and defaults for these parameters are listed in the following table.

Parameter	Default	Min	Max
AbsoluteMaxTransVel (LD-105CT)	1350	1	2500
AbsoluteMaxTransVel (LD-130CT)	900	1	2500
AbsoluteMaxTransNegVel (LD-105CT)	-210	-2500 ^a	-1
AbsoluteMaxTransNegVel (LD-130CT)	-140	-2500 ^a	-1
AbsoluteMaxTransAccel	1000	1	2000
AbsoluteMaxTransDecel	2000	1	2000
AbsoluteMaxRotVel	180	1	180
AbsoluteMaxRotAccel	360	1	360
AbsoluteMaxRotDecel	360	1	360

a: Although the Min value, in software, is -2500, the hardware safety system on the platform will generate a fault if the velocity is anything from -300 to -2500 mm/s.

4.5 Supplemental Information

Laser Setup

For most installations, the defaults for the lasers should be appropriate, and will not require any user adjustment.

The specific parameters for these lasers will come in the model config file that ships on the unit, or can be provided on request if needed.

- Laser_1 Settings are for the main scanning laser (S300), used both for safety and localization.
- Laser_2 Settings are for the low front laser (TiM).
- Laser_3 Tilted and Laser_4 Tilted are for the side lasers (TiM).
- Laser_5 Settings are for the coupling laser (TiM).
- Laser_6 Settings are the rear-facing laser (TiM).

Chapter 5: Payloads

5.1 Safety

Warning Label

A No Riding label ships, unattached, with each platform. You must place this in a prominent location on the payload, so operators will see it.



Other warning labels are applied at the factory.

Drive Warning Light

For CE compliance, an AIV is required to have a readily-visible warning light, when it is either ready to move or is moving. The platform comes with light discs on each side, and the HMI post has a beacon, designed to be higher than a normal payload, to do this.

If you have a payload that blocks the beacon, the core also provides an output, so you can add your own warning device. This may be necessary for taller payloads, which may make the beacon not always visible. The core has a Light Pole connector, which is covered in the Connectivity chapter in LD Platform Core Rear, Upper on page 96. This can be used to drive a warning light in a more prominent location for taller payloads.

Turn Warning Lights

An AIV is also required, for CE compliance, to have readily-visible turn warning lights, when it is either turning or about to turn. The platform's light discs indicate that the AIV is turning, and in which direction.

If you have a payload that blocks the beacon, the core also provides an output, so you can add your own warning device. This may be necessary for taller payloads, which may make the beacon not always visible. The core has a Light Pole connector, which is covered in the Connectivity chapter in LD Platform Core Rear, Upper on page 96. This can be used to drive a warning light in a more prominent location for taller payloads.

Warning Buzzer

The core provides an output for driving a warning buzzer. The default behavior of the buzzer is to sound when the AIV is moving in reverse, or when the safety systems are off. Its behavior is configurable by the user, so it can be used to sound, for example, whenever the AIV is moving.

5.2 Considerations

Dimensions

You must keep your payload no wider and no longer than the LD Platform Cart Transporter.

Take care to keep all of the sensors exposed. If any of the sensors get blocked, the AIV won't be able to function as intended. This is critical in the case of the lasers.

The payload design must not obstruct the side lasers' field of view.

If you have Acuity localization, you need to make sure that the height of your payload does not obstruct the camera's field-of-view. The Acuity camera lens has a 140° field-of-view, so take care that nothing higher than the camera lens is close beside the camera.

Pinch Hazard

There is a potential, with an improperly-designed cart payload, to create a pinch hazard between the payload and the HMI post.



CAUTION: PINCH RISK

Ensure that there is enough space between the HMI post and your payload, when the transporter and cart are coupling, so that it is not a pinch hazard.

Weight

Run-time between charges is a function of payload weight. A heavier payload will result in a shorter run-time. If you have added any options to the platform that draw power from the platform battery, that will also result in decreased run-time.

Center of Gravity

When adding payload, the center of gravity of the entire cart and payload needs to be considered.

As much as possible, you should keep the payload center of gravity centered on the platform, and as low (close to the platform top) as possible. This will give you the best stability, particularly when turning or crossing irregularities in the floor.

The payload should be centered on the cart left-to-right, but biased toward the rear of the cart according to the following plots.

The following figures show the calculations of safe placements for the center of gravity for payloads with the weights listed. The center of gravity, in each instance, needs to be within the area shown. All units are mm.

IMPORTANT: These figures show centers of gravity for the listed parameter settings only. They do not apply to any other parameter settings. Even small changes in these parameters can change the safe CG area drastically.

105 kg




Figure 5-1. Isometric View, 105 kg, (A) Vertical Direction, (B) Longitudinal Direction, (C) Transverse Direction (units in mm)




Figure 5-2. Longitudinal View, 105 kg, (A) Vertical Direction, (B) Longitudinal Direction (units in mm)




Figure 5-3. Transverse View, 105 kg, (A) Vertical Direction, (C) Transverse Direction (units in mm)




Figure 5-4. Top View, 105 kg, (B) Longitudinal Direction, (C) Transverse Direction (units in mm)

130 kg




Figure 5-5. Isometric View, 130 kg, (A) Vertical Direction, (B) Longitudinal Direction, (C) Transverse Direction (units in mm)




Figure 5-6. Longitudinal View, 130 kg, (A) Vertical Direction, (B) Longitudinal Direction (units in mm)




Figure 5-7. Transverse View, 130 kg, (A) Vertical Direction, (C) Transverse Direction (units in mm)




Figure 5-8. Top View, 130 kg, (B) Longitudinal Direction, (C) Transverse Direction (units in mm)

5.3 Payload-Related Tradeoffs

If you have to extend your center of gravity beyond the guidelines given here, you will need to adjust various parameters in the MobilePlanner software to compensate for that.

Contact your local Omron support to get a new set of plots based on parameters that differ from those used to produce the plots shown here.

In general, lowering the maximum accel, decel, and rotation speeds will be required. Refer to Acceleration, Deceleration, and Rotation Limits on page 73.

Chapter 6: Connectivity

Most of the connections that are available to the user are in the payload bay, which is the space between the platform and the platform top plate. These include I/O and power connections. Access to the payload bay is covered in Accessing the Payload Bay on page 156.

For a LD Platform Cart Transporter system, most of these connections will not usually be used.

The two connections outside of the payload bay are the Joystick port and the Maintenance Ethernet port, which are located under a small access panel on the left side of the platform, in the upper-right corner. Both of these ports connect to the core inside the payload bay.

6.1 Required Connections

- **Joystick port** In order to generate maps with the LD Platform Cart Transporter, you need to connect a joystick to its Joystick port.
The Joystick port is located under a small access panel on the left side of the platform, in the upper-right corner.
- **Maintenance Ethernet** The Maintenance Ethernet port is located under a small access panel on the left side of the platform, in the upper-right corner.
Its IP address is 1.2.3.4, with Netmask 255.255.255.0.
Access to the SetNetGo OS is always enabled on this interface, and does not require a password or a license.
- **Wireless Ethernet** For multi-AIV installations, or where you wish to send new commands or receive status updates from the AIV, you need to have wireless Ethernet.
- **Docking Station** The AIV needs access to a docking station so it can charge itself. The docking station needs access to AC power.

6.2 LD Platform Cart Transporter Connections

NOTE: All of these are in the payload bay.

NOTE: If a connection is covered in this subsection, it means that the description in the subsection Standard Platform Connections on page 89 does not apply to the LD Platform Cart Transporter, because that connection is being used for a cart-specific use.

Core

- RS232-2 is used for the rear-sensing laser.
- Both the Debug Port and Aux Power are used by the coupling laser.
- Digital I/O connector.


The transporter uses pins 9-16, both Input and Output.

Pins 1-8 are available on the cart PCA.

- User Power is used for cart PCA power.
- User Interface goes through the PCA to the Operator panel.
- Aux Sensors is used for both side lasers and the low front laser.
- Light Pole goes through the PCA to the Operator panel.
- User LAN goes to the Ethernet switch in the payload bay. Two ports are spares.

Cart-Specific PCA

NOTE: Contact your local Omron support for details.



Callout	Description	Callout	Description
A	User Beeper Out	E	User I/O Out 1-8
B	User EMO Out	F	User I/O In 1-8
C	User EMO Switch Connector	G	User Power Out
D	User Power		

User E_Stop (USER EMO OUT), J13. Micro MATE-N-LOK, mates with TE 6C 794617-6.

Pin No.	Designation	Notes
1	ESTOP 2A	Dry contact
2	ESTOP 2B	Dry contact
3	BRAKE	Use switch to connect to BATTERY (pin 5) for external brake release
4	ESTOP CTRLD POWER	(BAT) 1 A limit
5	BATTERY	1 A limit
6	GND	

User E-Stop Switch (USER EMO SWITCH), J39. Jumpers JP40 and JP41 must be moved to pins 1-2 for this to be functional. MiniFit Jr™, mates with MOLEX 4C 39-01-2045.

Pin No.	Designation	Notes
1	ESTOP 1A	
2	ESTOP 2A	
3	ESTOP 1B	
4	ESTOP 2B	

User Power, J15 & J16. MiniFit Jr™, mates with MOLEX 6C 39-01-2065.

Pin No.	Designation	Notes
1	GND	
2	GND	
3	GND	
4	5 V	2 A total
5	12 V	1.5 A total
6	BATTERY	22-28 V 1 A total

User Power, J37. Jumper JP5 selects battery (1/2) or E-Stop-controlled battery (2/3). MiniFit Jr™, mates with MOLEX 4C 39-01-2045.

Pin No.	Designation	Notes
1	BATTERY	1.8 A
2	GND	
3	N.C.	
4	SHIELD GND	

User I/O Outputs, J19 - J26. Micro MATE-N-LOK, mates with TE 2C 794617-2.

The return is common for each bank of four outputs, with the indicated jumper.

Connector	Designation	Notes
J19	OUT1	JP13, LED DS14
J20	OUT2	JP11, LED DS15
J21	OUT3	JP10, LED DS16
J22	OUT4	JP12, LED DS17
JP26	RETURN	Selects HI or LO for J19-J22
J23	OUT5	JP17, LED DS10
J24	OUT6	JP15, LED DS11
J25	OUT7	JP14, LED DS12
J26	OUT8	JP16, LED DS13
JP27	RETURN	Selects HI or LO for J23-J26

Pin No.	Designation	Notes
1	RETURN	0 or Battery, 22-29 VDC
2	OUTPUT	HI (BAT) or LO (GND)




Figure 6-2. Output Schematic

Callout	Description	Callout	Description
A	Output High Side Drivers	B	Set JP26 and 27 to 2/3 for Active High Out Set remaining Jumpers to 2/3 for Active Low Out

User I/O Inputs, J40, J45 - J51. Micro MATE-N-LOK, mates with TE 4C 794617-4.

The return is common for each bank of four inputs, with the indicated jumper.

Connector	Designation	Notes
J40	IN1	LED DS26
J45	IN2	LED DS27
J47	IN3	LED DS29
J46	IN4	LED DS28
JP6	RETURN	Selects SINK LO or SOURCE HI for J40, J45-47
J51	IN5	LED DS33
J50	IN6	LED DS32
J49	IN7	LED DS31
J48	IN8	LED DS30
JP7	RETURN	Selects SINK LO or SOURCE HI for J48 - J51

Pin No.	Designation	Notes
1	BATTERY	22-29 VDC, 0.4 A TOTAL
2	GND	HI (BAT) or LO (GND)
3	SENSOR	
4	SHIELD GND	




Figure 6-3. Input Schematic

Callout	Description	Callout	Description
A	Jumpers shown as ACTIVE LOW IN Move to 2/3 position ACTIVE HIGH IN	C	INPUTS 9-16 Have options for PIC outputs
B	INPUTS 1-8 Targeted for ACTIVE LOW IN, 9-16 for ACTIVE HIGH IN.		

User Beeper, J56. Micro MATE-N-LOK, mates with TE 2C 794617-2.

This signal goes low when the platform is moving. It can be used to drive a beeper.

Pin No.	Designation	Notes
1	BATTERY	22-29 VDC, 0.1 A
2	SOUNDER	ACTIVE LOW

6.3 Standard Platform Connections

NOTE: All of these are in the payload bay.

If there is no conflicting connection in the Connectivity on page 83, these connections are available for use with standard- and user-supplied accessories. The antennas and joystick come with the platform.

NOTE: If a connection is in Connectivity on page 83, it means that the description here does not apply to the LD Platform Cart Transporter, because that connection is being used for a cart-specific use.

NOTE: Standard connectors, such as audio, are not covered here. These are on the right side of the core, shown in the following figure:




Figure 6-4. Right Side of the Core

The left end of the LD Platform core has 12 indicator lights. Their meanings are covered in LD Platform Core Indicators on page 128.

LD Platform Core Front, Upper




Figure 6-5. Front Upper Core

Connection	Type	Description
User LAN	RJ45, Shielded	General Ethernet, Auto-MDIX.
Aux Sensors	HDB15M	Side lasers
RS-232 x 2	DB9M	Port 1 and Port 2, general use
CAN Bus B	DB9F	Consult Support for use.
Digital I/O (HDB44F)	HDB44F	<p>16 digital inputs, in 4 banks of 4. Each bank can be wired as active high or active low depending on the connection of the BANK# terminal. V_{IN} range for each input is 0 to 30 V. The input is ON when $V_{IN} > 4$ V, OFF when $V_{IN} < 1.3$ V.</p> <p>16 digital outputs, protected low-side drivers. These outputs should be wired to positive voltage through the load. Output is open when OFF and grounded when ON. Each open-drain output is capable of sinking 500 mA. May be used with loads connected to VBAT, AUX_20V, _12V, or _5V. You must stay within the allowed current capacity of the VBAT or AUX power supplies.</p>
Analog I/O	HDB15M	General use

CAN Bus B

Connector type DB9F

Use CAN Bus

Pin No.	Designation	Notes
1, 4, 8	No Connection	

Pin No.	Designation	Notes
2	CANL_B	CAN Communication differential pair
3, 6	GND	Direct GND
5	SHIELD GND	Bead filter to GND
7	CANH_B	CAN Communication differential pair
9	CANB_12V_OUT_SW	12 V @ 0.5 A Max (switched in SW)

Digital I/O

Connector type HDB44F

Pin No.	Designation		Notes
	Hardware	Software	
1	INPUT_1.1	Input_1.1	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
2	INPUT_1.2	Input_1.2	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
3	INPUT_1.3	Input_1.3	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
4	INPUT_1.4	Input_1.4	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
5	BANK1		Common for INPUT_1.X
6	INPUT_2.1	Input_2.1	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
7	INPUT_2.2	Input_2.2	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
8	INPUT_2.3	Input_2.3	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
9	INPUT_2.4	Input_2.4	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
10	BANK2		Common for INPUT_2.X
11	INPUT_3.1	Input_3.1	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
12	INPUT_3.2	Input_3.2	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
13	INPUT_3.3	Input_3.3	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
14	INPUT_3.4	Input_3.4	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
15	BANK3		Common for INPUT_3.X
16	INPUT_4.1	Input_4.1	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
17	INPUT_4.2	Input_4.2	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
18	INPUT_4.3	Input_4.3	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
19	INPUT_4.4	Input_4.4	0-30 V Range, $R_{in} = \sim 3.9 \text{ k}\Omega$
20	BANK4		Common for INPUT_4.X
21	OUTPUT_1	Output_1	

Pin No.	Designation		Notes
	Hardware	Software	
22	OUTPUT_2	Output_2	
23	OUTPUT_3	Output_3	
24	OUTPUT_4	Output_4	
25	OUTPUT_5	Output_5	
26	OUTPUT_6	Output_6	
27	OUTPUT_7	Output_7	
28	OUTPUT_8	Output_8	
29	OUTPUT_9	Output_9	
30	OUTPUT_10	Output_10	
31	OUTPUT_11	Output_11	
32	OUTPUT_12	Output_12	
33	OUTPUT_13	Output_13	
34	OUTPUT_14	Output_14	
35	OUTPUT_15	Output_15	
36	OUTPUT_16	Output_16	
37	VBAT_IO_OUT4		VBAT @ 0.5 A Max (shared with light pole)
38	VBAT_IO_OUT3		VBAT @ 0.5 A Max
39	VBAT_IO_OUT2		VBAT @ 0.5 A Max
40	VBAT_IO_OUT1		VBAT @ 0.5 A Max
41, 42, 43, 44	GND		

Digital Input Specifications

Parameter	Value
Operational voltage range	0 to 30 VDC
OFF state voltage range	0 to 1.3 VDC
ON state voltage range	4 to 30 VDC
Operational current range	0 to 7.5 mA
OFF state current range	0 to 0.5 mA
ON state current range	1.0 to 7.5 mA
Impedance (V_{in}/I_{in})	3.9 k Ω minimum

Parameter	Value
Current at $V_{in} = +24 \text{ VDC}$	$I_{in} \leq 6 \text{ mA}$

NOTE: The input current specifications are provided for reference. Voltage sources are typically used to drive the inputs.




Figure 6-6. Typical Digital Input Wiring Example

Callout	Description	Callout	Description
A	Supplied Equipment	H	Input Bank 1
B	User-Supplied Equipment	J	Input Bank 2
C	Wiring Terminal Block	K	Input Bank 3
D	Typical User Input Signal	L	Input Bank 4
E	Part Present Sensor	M	Note: all input signals can be used for either sinking or sourcing configurations.

Callout	Description	Callout	Description
F	Bank 1 configured for sinking (NPN) inputs	N	Equivalent Circuit
G	Bank 4 configured for sinking (PNP) inputs		

Table 6-1. Digital Output Specifications

Parameter	Value
Power supply voltage range	5-30 VDC
Operational current range, per channel	$I_{out} \leq 500 \text{ mA}$
ON state resistance ($I_{out} = 0.5 \text{ A}$)	$R_{on} \leq 0.14 \Omega @ 85^\circ\text{C}$
Output leakage current	$I_{out} \leq 5 \mu\text{A}$
DC short circuit current limit	$0.7 \text{ A} \leq I_{LIM} \leq 1.7 \text{ A}$




Figure 6-7. Typical Digital Output Wiring Example

Callout	Description	Callout	Description
A	Standard Equipment	E	Load
B	User-Supplied Equipment	F	Outputs 1-16
C	Wiring Terminal Block	G	Equivalent Circuit
D	Typical User Loads		

Analog I/O

Connector type HDB15M

Pin No.	Designation	Notes
1	ANALOG_IN1	0-10 V Range
2	ANALOG_IN2	0-10 V Range
3	ANALOG_IN3	0-10 V Range
4	ANALOG_IN4	0-10 V Range
5	ANALOG_IN5	0-30 V Range
6	ANALOG_IN6	0-30 V Range
7	ANALOG_IN7	0-30 V Range
8	ANALOG_IN8	0-30 V Range
9	ANALOG_OUT1	0-20 V Range
10	ANALOG_OUT2	0-20 V Range
11	ANALOG_OUT3	0-20 V Range
12	ANALOG_OUT4	0-20 V Range
13, 14, 15	GND	

- The 0-10 V analog inputs have an input impedance of about 35 k Ω .
- The 0-30 V analog inputs have an input impedance of about 110 k Ω .
- The analog outputs have an output impedance of about 200 Ω .

The maximum output current of each analog output is 10 mA. Exceeding the maximum output current will result in damage to the analog output module.

Aux Sensors

Connector type HDB15M

Use Side (vertical) and low sensing (foot) lasers

Pin No.	Designation		Notes
	Hardware	Software	
1	RS232_VERT1_TXD		/dev/ttyUSB5
2	RS232_VERT2_TXD		/dev/ttyUSB6
3	RS232_FOOT_TXD		/dev/ttyUSB7
4	5V_SW1	USB_1_and_2_Power	5 V @ 1 A (shared with USB port 1)


Pin No.	Designation		Notes
	Hardware	Software	
5, 10	SW_20V_VERT	Vertical_Laser_Power	20 V @ 300 mA
6, 7, 8	GND		
9	5V_SW2	USB_1_and_2_Power	5 V @ 1 A (shared with USB port 2)
11	RS232_VERT1_RXD		/dev/ttyUSB5
12	RS232_VERT2_RXD		/dev/ttyUSB6
13	RS232_FOOT_RXD		/dev/ttyUSB7
14	5V_SW3	USB_3_Power	5 V @ 1 A (shared with USB port 3)
15	SW_20V_FOOT	Foot_Laser_Power	20 V @ 150 mA

RS232 1 & 2

Connector type DB9M

Use Port 1 and 2, General Use

Pin No.	Designation	Notes
1, 4, 6, 9	No Connection	
2	RS232_USR#_RXD	# = 1 or 2
3	RS232_USR#_TXD	# = 1 or 2
5	GND	
7	RS232_USR#_RTS	# = 1 or 2
8	RS232_USR#_CTS	# = 1 or 2

LD Platform Core Rear, Upper*Figure 6-8. Rear Upper Core*

NOTE: The connectors in the top row of the Rear Upper Core mate with Molex Mini-Fit Jr™ 5557 series receptacles.

Callout	Connection	Type	Description
A	Light Pole	Mini-Fit 2 x 3	Connects to a user-supplied light tower with 3 lights and 1 buzzer, using a default configuration
NOTE: The following four functions are pins on the User Interface connector.			
B	Brake-release	Mini-Fit 2 x 7	Pins for user-supplied brake release
	ON		Pins for user-supplied ON button
	OFF		Pins for user-supplied OFF button
	ESTOP		Pins for user-supplied E-Stop (must be used or jumpered)
C	User Bumpers	Mini-Fit 2 x 4	This connection is not used with an LD Platform Cart Transporter.
D	Aux Power	Mini-Fit 2 x 3	5, 12, and 20 VDC Outputs
E	User Power	Mini-Fit 2 x 6	Battery and switched battery power
J	Maint LAN	RJ45, Shielded	Directly connected to the externally-mounted Maintenance Ethernet, Auto-MDIX.
H	Joystick	DB9F	Directly connected to the externally-mounted Joystick port
G	HMI Panel	HDB15F	Operator screen, E-Stop, Brake_Rel, ON, OFF
F	Sonar 2	DB9M	This connection is not used with an LD Platform Cart Transporter.

Power Connections

The platform provides conditioned 5, 12, and 20 VDC, and raw (battery) 22 - 30 VDC power to the platform's and accessory electronics, including the onboard LD Platform core and safety scanning laser LIDAR (Light Detection And Ranging).

All power connectors are Mini-Fit®.

Nominal	Qty	Actual	Maximum Current	Description
5 VDC	1	5±5% VDC	1 A	Switched Aux power
12 VDC	1	12±5% VDC	1 A	Switched Aux power
20 VDC	1	20±5% VDC	1 A	Switched Aux power
22 – 30 VDC	2	battery	4 A	Switched

Nominal	Qty	Actual	Maximum Current	Description
22 – 30 VDC	1*	battery	10 A	Switched
22 – 30 VDC	1*	battery	10 A	Safe, Switched
* 10 A Switched and 10 A Safe, Switched share the 10 A of current.				

Each supply has an associated LED, which, when lit, indicates that the port is actively powered. See LD Platform Core Indicators on page 128.

The Safe 22 - 30 VDC supply automatically gets disconnected when the E-Stop button is pressed or an obstacle is detected.

Light Pole

Connector type Mini-Fit® 3 x 2

Use Light tower (user-supplied)

Pin No.	Designation	Notes
1	GND	Cable shield
2	LIGHT_P1	Red
3	LIGHT_P2	Yellow or orange
4	VBAT_IO_OUT4	VBAT @ 0.5A Max (shared with DIO)
5	LIGHT_P3	Green
6	LIGHT_P4	Buzzer




Figure 6-9. Sample Light Pole Diagram

Callout	Description	Callout	Description
A	Standard Equipment	D	Typical User Load
B	Wiring Terminal Block	E	Equivalent Circuit
C	User-Supplied Equipment		

User Interface

Connector type Mini-Fit® 7 x 2

Use Brake release, ON, OFF, E-Stop

Pin No.	Designation	Notes
1, 2, 3	FBAT_ALWAYS	Fused VBAT @ 500 mA
4	ESTOP_USR_1L	Short 4 & 11 to close ESTOP_USR_1
5	ESTOP_USR_2L	Short 5 & 12 to close ESTOP_USR_2
6	ESTOP_OUT_1L	Pins 6 & 13 short when ESTOP_CH1 is closed
7	ESTOP_OUT_2L	Pins 7 & 14 short when ESTOP_CH2 is closed
8	OFF_BUTTON	Short to FBAT_ALWAYS to signal OFF (min 1 s pulse)
9	START_BUTTON	Short to FBAT_ALWAYS to signal ON (min 1 s pulse)
10	MOTOR_BRAKE	Short to FBAT_ALWAYS for manual brake release
11	ESTOP_USR_1H	Short 4 & 11 to close ESTOP_USR_1
12	ESTOP_USR_2H	Short 5 & 12 to close ESTOP_USR_2
13	ESTOP_OUT_1H	Pins 6 & 13 short when ESTOP_CH1 is closed
14	ESTOP_OUT_2H	Pins 7 & 14 short when ESTOP_CH2 is closed

NOTE: An E-Stop jumper or a user-supplied E-Stop button needs to be attached to the E-STOP port on the User Interface connector for the platform to function. The jumper is provided as part number 12730-000L. An E-Stop button would be user-supplied.

NOTE: Engaging the E-Stop through the external connector or Operator Panel (faster than 250 ms), will cause motors to re-engage after E-stop is released. Motor re-engagement occurs because the core is designed to receive a consistent E-Stop signal for at least 250 ms. Signals that engage and disengage in a time period shorter than 250 ms, will cause LD to assume that the change was due to a bumper press, which will automatically re-engage the motors. No signal on the E-Stop chain can cause the robot to operate while the E-Stop remains engaged. Thus it is necessary to leave the E-Stop engaged, if the intent is to keep the robot in a E-Stop state.



CAUTION: PERSONAL INJURY OR PROPERTY DAMAGE RISK

If you are using a user-supplied E-Stop, you must run the Safety Commissioning to verify the E-Stop's functionality before putting the AIV into service.

NOTE: See the following figure.




Figure 6-10. E-Stop Jumper on Platform Core




Figure 6-11. E-Stop Chain Diagram

Callout	Description	Callout	Description
A	Standard Circuits	H	Bumper Right
B	User-Supplied Circuits	J	E-STOP Relay Control Logic
C	E-STOP-Source	K	Voltage of the Battery
D	Ground	L	High Power to Amplifiers

Callout	Description	Callout	Description
E	Front Panel E-STOP	M	HMI Connector
F	User E-STOP	N	Note: Jumper closed when not used, MUST open both channels independently if used.
G	Bumper Left	O	User Interface Connector

User Bumper

This connection is not used with an LD Platform Cart Transporter.

Aux Power

Connector type Mini-Fit® 3 x 2

Pin No.	Designation		Notes
	Hardware	Software	
1, 2, 3	GND		
4	AUX_5V_OUT	Aux_5V	5 V @ 1 A max
5	AUX_12V_OUT	Aux_12V	12 V @ 1 A max
6	AUX_20V_OUT	Aux_20V	20 V @ 1 A max

User Power

Connector type Mini-Fit® 6 x 2

Pin No.	Designation		Notes
	Hardware	Software	
1, 2, 3, 4, 5, 6	GND		
7	SW_VBAT_OUT1	Battery_Out_1	VBAT @ 4 A max (switched in SW)
8	SW_VBAT_OUT2	Battery_Out_2	VBAT @ 4 A max (switched in SW)
9, 10*	SW_VBAT_OUT34	Battery_Out_3_and_4	VBAT @ 10 A max (switched in SW). Limit to < 5 A per pin.
11, 12*	SAFE_VBAT_OUT		SW_VBAT_OUT34 gated by dual-channel ESTOP relays.
*9, 10, 11, and 12 share the 10 A of current.			

Joystick

Connector type DB9F

Use Joystick

Pin No.	Designation	Notes
1	JOY_XAXIS	Analog X input
2	JOY_YAXIS	Analog Y input
3	JOY_SPEED	Analog SPEED input

Pin No.	Designation	Notes
4	JOY_GOAL	Goal Button Input
5	JOY_EN_1H	Enable channel 1
6	JOY_EN_2L	Enable channel 2
7	No Connection	
8	GND	
9	5V	5 V @ 100 mA

HMI Panel

Connector type HDB15F

Use Operator screen, E-Stop, Brake_Rel, ON, OFF

NOTE: The HMI panel that this connects to is not the touchscreen used for the LD Platform Cart Transporter. The HMI panel is not used with the LD Platform Cart Transporter, so this connector is not used.

Pin No.	Designation		Notes
	Hardware	Software	
1	RS422_HMI_TX+		Connections to HMI Panel NOTE: This is not the touch-screen.
2	RS422_HMI_TX-		
3	MOTOR_BRAKE		
4, 5	ESTOP_FP_1H, _2H		
6	RS422_HMI_RX+		
7	RS422_HMI_RX-		
8	START_BUTTON		
9, 10	ESTOP_FP_1L, _2L		
11	HMI_5V_SW	HMI_Power	
12, 14	GND		
13	OFF_BUTTON		
15	FBAT_ALWAYS		

Sonar 1 & 2

This connection is not used with a cart.

NOTE: Sonar 1 is part of the Internal Core connections.

Internal LD Platform Core Connections

The following connections are internal (under the platform's top deck), and not normally available for the user. They are listed here so that you can reconnect them in the event that they need to be disconnected for parts replacement.




Figure 6-12. Internal Connectors on the LD Platform Core (Front)

NOTE: The Bumper, Speakers, and Batt Comm. connectors on the internal core mate with Molex Mini-Fit Jr™ 5557 series receptacles.

NOTE: The Charge Contacts and Battery Power connectors on the internal core mate with Molex Mini-Fit Jr™ 42818 series receptacles.

Callout	Connection	Type	Description
A	Debug RS-232	DB9M	Reserved
B	Wheel Lights	DB9F	Motion and status indicator Light Discs on the platform sides
C	Sonar 1, RS-422	DB9M	Connection to Sonar Module (Rear sonar sensors)
D	Charge Contacts	Mini-Fit Sr., 2-pin	

Callout	Connection	Type	Description
E	VGA	HDB15F	Reserved
F	USB x 3	USB Type A	Reserved
G	LIDAR	HDB26M	Safety Scanning Laser
H	Right Motor	HDB26F	NOTE: The Right and Left Motor connectors use the same type of plug. Take care not to reverse them.
J	Left Motor	HDB26F	
K	Battery Power	Mini-Fit Sr., 3-pin	Battery VDC; connects to battery
L	Bumper Switches	Mini-Fit 2 x 4	This connection is not used with a LD Platform Cart Transporter.
M	Speakers	Mini-Fit 2 x 2	Drives built-in speakers
N	Battery Comm.	Mini-Fit 2 x 3	Battery communication/control

Core Internal Data Pinouts

Wheel Lights (Light Discs)

Connector type DB9F

Use Motion and status indicator Light Discs on the platform sides

Pin No.	Designation		Notes
	Hardware	Software	
1, 2	CANL_A		CAN Communication differential pair
3, 4	GND		Direct GND
5	SHIELD GND		Bead filter to GND
6, 7	CANH_A		CAN Communication differential pair
8, 9	SW_12V_WHEEL	WheelLight_Power	12 V @ 1 A Max (switched in SW)

NOTE: Sonar 1 is covered at the end of Core, Upper Rear.

LIDAR (Light Detection And Ranging)

Connector type DB26M

Use Front safety scanning laser

Pin No.	Designation		Notes
	Hardware	Software	
1	RS422_LIDAR_RX+		Connections to Factory-Supplied LIDAR
2	RS422_LIDAR_RX-		
3	OSSD1		
4	OSSD2		
5	WF_OUT		
6	O3_OUT		
7	STANDBY		
8	EDM		
9	No Connection		
10, 18	SW_20V_LIDAR	Main_Laser_Power	
11 thru 17	GND		
19	RS422_LIDAR_TX+		
20	RS422_LIDAR_TX-		
21	IN_A1		
22	IN_A2		
23	IN_B1		
24	IN_B2		
25	IN_C1		
26	IN_C2		

Pin 10 + 18: Current < 600 mA

LD Platform Core Internal Power Pinouts

Bumper

Connection Mini-Fit® 4 x 2

Connector type DB9F

Use Front bumpers

NOTE: The single front bumper uses four sensors for operation.

Pin No.	Designation	Notes
1	BUMPER_R2L	Right, Channel 2, Low
2	BUMPER_R1L	Right, Channel 1, Low
3	BUMPER_L2L	Left, Channel 2, Low
4	BUMPER_L1L	Left, Channel 1, Low
5	BUMPER_R2H	Right, Channel 2, High
6	BUMPER_R1H	Right, Channel 1, High
7	BUMPER_L2H	Left, Channel 2, High
8	BUMPER_L1H	Left, Channel 1, High

Speakers

Connector type Mini-Fit® 2 x 2

Use Speakers

Pin No.	Designation	Notes
1	RIGHT+	Right Speaker
2	RIGHT-	
3	LEFT+	Left Speaker
4	LEFT-	

Batt Comm.

Connector type Mini-Fit® 3 x 2

Use Battery control

Pin No.	Designation	Notes
1	GND	Connections to the Factory-Supplied Battery
2	RS232_BATT_RXD	
3	RS232_BATT_TXD	
4	FBAT_ALWAYS	
5	START_BUTTON	
6	OFF_BUTTON	

Chapter 7: Operator Interface

The Operator panel comprises a touchscreen, an E-Stop button, ON and OFF buttons, a brake-release (BRAKE) button, a keyswitch, and LATCH and UNLATCH buttons. The panel is mounted on the HMI post, so that it is easily reached by an Operator.



Figure 7-1. Operator Panel, with Acuity Option Shown

7.1 Touchscreen

Touchscreen Initialization

When first powered up, the bottom of the touchscreen will display its boot status.

1. Initializing robot core connection...

NOTE: This may take a minute or two to initialize.

2. Initializing touchscreen software...
3. Connecting to the robot core...
4. Downloading data from the robot core...




Figure 7-2. Screen Initialization Status Display

After initialization, either the Choose Dropoff or Patrol Route screen will be displayed.

Touchscreen Configuration

The behavior of the touchscreen is highly configurable. See [Configuring a Touchscreen](#) on page 66.

Screen Top Bar

The top of the screen shows basic AIV information. This includes a bar graph indicating the WiFi signal strength, the name of the AIV, and the battery state of charge. If the AIV is connected to an Enterprise Manager, it will also be specified here.

Left Screen Pane

The screen logo is displayed in the upper part of the left pane. This doesn't change, regardless of the mode you are in. See [Screen Logo](#) on page 70.

Below the screen logo, the AIV status is displayed, first graphically, and below that, in text.




Figure 7-3. Screenshot Showing Top Bar and Left, Right, and Center Panes




Figure 7-4. LD Platform Cart Transporter Status Icons

NOTE: The Busy icon may also include an arrow pointing down, indicating a pickup, an arrow pointing up, indicating it is doing a dropoff, or an exclamation mark, indicating an alert condition. Figure 7-3. shows a dropoff.

The bottom of the left side of the touchscreen provides a Stay button, to delay the departure of the AIV, and a count-down timer, indicating when the AIV will depart.

Each touch of the Stay button adds 1 minute to the time the AIV will wait before continuing to its next goal.

- If you touch Stay while the AIV is stopped, it will add 1 minute to the time the AIV is scheduled to wait before continuing to its next goal.
- If you touch Stay while the AIV is moving, it will stop, and stay for 1 minute.

NOTE: The Stay count-down timer can be zeroed at any time by touching Go at the bottom of the center pane.

The screensaver can be set up to behave the same way the Stay button does, so that touching the screensaver adds 1 minute to the time the AIV will wait. See Screensaver on page 71.

Right Screen Pane

The right side of the touchscreen displays Home, Dropoffs, Status, and Help tabs. touching one of these tabs changes the context of the center pane.

Home Tab

NOTE: The Dropoffs tab is not displayed in Patrol Route mode.

The Home tab is used to switch the center pane to show the AIV's current mission. If an error condition exists, such as the AIV overheating or being lost, the software will automatically select the Home tab. See the following figure.




Figure 7-5. Payload Alert, Displayed from the Home Tab

The preceding screen will not be displayed unless the configuration has been set up in the MobilePlanner software:

Config > Robot Physical > Payload > NumSlots

This must be set to a non-zero value, i.e. the number of payload slots.

Config > Robot Interface > Payload Present Messages and Behavior

- The AlertWhenPayloadNeededForDropoff must be checked.
- The PayloadNeededForDropoffShortDescription must have a value. In this case, the value is “Payload Needed”, which is displayed in the screen’s left pane.
- The PayloadNeededForDropoffLongDescription must have a value. In this case, the value is “The robot has a destination but does not have a payload. Please load an item or cancel the dropoff.” This will be displayed in the screen’s center pane.

NOTE: The payload parameter section will not be displayed unless the payload slots at the top of the Payload Present Messages and Behavior are set to a non-zero value.

The Home screen also has an entry for relocalizing a lost AIV from the touchscreen. See Relocalization on page 118.

When you select Home from the right pane tabs (rather than when the software switches to Home), the center pane will display information about the AIV’s current mission, such as the job details or the current route task.

Dropoffs Tab - Choose Dropoff mode only

Dropoffs shows the available goals, giving the Operator the ability to choose the next goals, and shows the status of the AIV with respect to the goals it has been assigned.

In Patrol mode, this option isn’t displayed.

Status Tab

After touching the Status tab, you will be given a choice of either Alerts, Robot, I/O, or Peripherals (which accesses screen-cleaning mode).

The number of alert messages that are available for viewing is indicated by a number in a red circle on the Status button. See the preceding figure.




Figure 7-6. Status Tab and Sub-menu

- Alerts shows an abbreviated list of all active alert messages.

Touching on a specific message will display that full message.

- Robot shows AIV status, such as the IP address, current task, and its mode.

Position Details, within the Robot Status screen, shows the AIV's position, heading, velocity, and localization score.

- I/O will display any of the Core Digital Inputs / Outputs that have been configured as a "custom" type



Figure 7-7. Status > I/O Screen (Top Inputs are not shown in this example)

- Peripherals > Touchscreen allows you to lock the touchscreen, so that you can clean the screen without it interpreting that as input. The screen stays locked for one minute, and then returns to normal function.

Help Tab

Help shows information on the installed software and contact information.

NOTE: No contact information will be displayed unless it is set up in the MobilePlanner software. See Contact Information on page 73.




Figure 7-8. Help > Contact Information

Help also provides access the Replay Recorder page.

Replay Recorder

The replay recorder will record data for troubleshooting. Once the start page is opened, you just touch Start. When you are done recording, touch Stop. The Duration and Replay File fields are filled in by the recorder. After the recording is completed, use the MobilePlanner software to download the file generated.




Figure 7-9. Replay Recorder Start Page



Figure 7-10. Replay Recorder, After Touching Stop

Center Pane

The content of the center pane changes depending on what has been selected from the right pane. The bottom of the center pane will almost always have a Go button, to zero the Stay count-down timer, and tell the AIV to proceed to its next goal.

Relocalization

The touchscreen gives you a way to relocalize the AIV if it becomes lost. Before you can do that, you need to have set up at least one localization goal, with a heading, at which the AIV can localize. You can set up multiple such goals, if you like. See Localization Goals on page 69.

If the AIV becomes lost, the touchscreen will automatically select the Home tab (from the right pane), and display a message indicating that the AIV is lost. It will also offer an option to Recover.

1. Touch Recover.
2. Follow the on-screen instructions.

You will be instructed to manually move the AIV to a localization goal, and then tell the software which goal you moved the AIV to.

Choose Dropoff Mode

In this mode, the touchscreen communicates with the queuing manager, which then communicates with the AIV.

Dropoffs

NOTE: Until the queuing manager has been enabled, the touchscreen will not display any of the dropoff goal buttons. Refer to the *Mobile Robot Software Suite User's Guide*.

In this mode, the center of the screen displays touch-sensitive dropoff buttons, indicating the goals associated with them. If there are more buttons than can be displayed at once, a sliver of the adjacent row of buttons is shown, to indicate their existence. See Screenshot Showing Top Bar and Left, Right, and Center Panes on page 113.

Navigation of the center pane, when there are more buttons than can be displayed at one time, is done by touching the screen, between buttons, and dragging the pane up or down.

The color and border of a dropoff button indicate the status of the associated job.

Status	Color	Border	Cancel	Priority
Ready	Blue	None	n/a	n/a
Planned	Dark Blue	None	Yes	Yes
Requested	Dark Blue	None	Yes	Yes
Pending	Dark Blue	Med. Blue	Yes	Yes
In progress	Dark Blue	Green	Yes	No
Interrupted	Dark Blue	Orange	Yes	No
Completed/Canceled	Blue	None	n/a	n/a

The Operator can use this pane for entering the goals where they want the AIV to go for dropoffs, after leaving its current location.

Touching a dropoff button and then Go requests that the AIV be sent to that goal. Touching several buttons in sequence, followed by touching Go, requests that the AIV be sent to all of those goals, in the order in which the dropoff buttons were touched. The order may be altered by assigning high-priority to any of the goals.

The number of buttons, the content of each button, and the goal associated with each button is configured with the MobilePlanner software.

- Goals will be serviced by the AIV in the order in which you touch their buttons.
- The selected dropoff goals are not sent to the queuing manager until you touch Go. After being received by the queuing manager, each goal is considered to be a job.
- Touching a Planned (selected) dropoff button will de-select it, without affecting other Planned dropoff buttons.

Simply touching a Pending or In-Progress goal button will not affect the associated job. An explicit Cancel is required to cancel a job in either of those states.

- Buttons will change appearance when you select/de-select them, change their priority, when the job is received by the queuing manager, when an AIV is on its way to the button's goal, and when the job is completed (and AIV dismissed).

Cancel Request (X)

When a dropoff button has a blue or green border, meaning its job is Pending or In Progress, the Operator can touch the button and a Cancel pop-up button (X) will be displayed on the button. Touching that pop-up will cancel the job for that goal. This does not affect any other jobs. See Touchscreen Dropoff Goals Page, with Cancel and Hi-Priority Pop-ups on page 120.

High Priority (!)

If you touch-and-hold the dropoff button for a goal that is planned or requested, or simply touch the button for a job that is pending, a High-Priority pop-up button (!) is displayed. Touching this pop-up will toggle the priority for the goal or job between high and normal priority. See the following graphic.

When a job is assigned high priority, its dropoff button will display a visible high-priority indicator (!). A high-priority job will be serviced before all normal-priority jobs, even if those jobs were entered at an earlier time.

This means that if you touch Goal1, then Goal2+HighPriority, then Goal3, they will be serviced in this order: Goal2, Goal1, Goal3.

If you de-select a high-priority dropoff button, and then re-select it, it will appear as normal priority (the high-priority flag is not persistent).

NOTE: Changing a high-priority dropoff button or job to normal priority will move that button or job to the end of the queue, so it will be serviced last.




Figure 7-11. Touchscreen Dropoff Goals Page, with Cancel and Hi-Priority Pop-ups



Figure 7-12. Touchscreen Dropoff Goals Page, with Stay and Count-down Timer

Stay Button

If the AIV is en route to a goal when Stay is touched, that goal's button will be turn dark blue with an orange border.

If the AIV has entered a wait task associated with a goal or job, touching Stay merely extends that wait, and the button border stays green. (The job isn't interrupted from the queuing manager's perspective, the wait task has just been prolonged.)

Go Button

The bottom of the center pane, in Dropoffs and user-selected Home mode, is a Go button. This zeroes the countdown timer, and causes the AIV to immediately proceed to its next goal. This can be used in conjunction with the Stay button to pause the AIV, and give the Operator more time to load or unload the payload.

Patrol Route Mode

The AIV does not communicate with the queuing manager in this mode.




Figure 7-13. Touchscreen, Patrol Route Page, in Stay Mode

An Operator can touch Stay, to pause the AIV, and Go to release it, but the Operator cannot select the AIV's next goal. That is determined by the patrol route.

7.2 Operator Panel

E-Stop Button

When pressed, the red, latching push-button prevents any transporter motion by disabling the motors. To reset the E-Stop, twist the button slightly, so it pops up.

The motors must be explicitly enabled, either with the dialog box that will pop up (MobilePlanner software with **Map > Show Robot on**), with the ON button, or with an ARCL command. See the following figure:




Figure 7-14. Motor Enable Pop-up Dialog

In normal use, the E-Stop button is used for three primary purposes:

- You need to interrupt or stop the platform for some reason, to keep it from performing its currently scheduled task (and don't have access to MobilePlanner).
- You are working near the platform and don't want it to move.
- You want to use the Brake Release button.

NOTE: There is a two-second delay between the manual release of an E-Stop and the transporter resuming its activity. During the two seconds, the transporter scans its path for potential obstacles. It will resume commanded motion provided there is adequate space to maneuver.

ON Button

The ON button is used for restoring power after the OFF button has been pressed, and the software has finished shutting down the platform.

It can also be used to restore power after an E-Stop has been pressed.

OFF Button

The red OFF button removes power from all systems except the charging hardware circuits. The platform's software systems prevent loss of data on shutdown, and save the AIV's last known location so it automatically localizes when it is next powered on.

NOTE: The OFF button can be disabled by the keyswitch, which can be locked and the key removed.

Brake-release (BRAKE) Button

The brake-release releases the brakes on the platform. It is used when you need to manually move the AIV.

Battery power is required and an E-Stop must be pressed to release the brakes.

The BRAKE button must be held in to keep the brakes released.

Version Information: The LD-130CT is difficult to move manually, even using the brake release.

Keyswitch

The keyswitch can be used to disable the OFF button. The key can be removed in either the locked or unlocked positions.

LATCH Button

The Operator can manually make the platform latch to the cart by pressing this button. The platform must be in the correct position for latching with the cart for this to work. The button's light will be lit blue when this is enabled.

UNLATCH Button

The Operator can manually unlatch the platform from the cart by pressing this button. The button's light will be lit blue when this is enabled.

7.3 Other Controls and Indicators

A beacon is mounted on the top of the HMI post. See Operator Panel, with Acuity Option Shown on page 111.

Light Discs and Beacon


Circular lights on the sides of the platform are used to indicate motion, turns, and several other states.

A beacon is used to indicate movement and to signal an Operator that the AIV is waiting for assistance.

Their states are described here, and summarized in the following tables.


Driving Straight

Blue arcs on each side of the platform will appear to rotate in the direction of the platform's travel, to let nearby people know that it is moving (or about to move). Beacon blinks green.




Turn Signal (for turns >30 degrees)

The blue drive indicators will include a blinking orange segment at the front of one light disc to indicate that the platform is about to turn in the direction of the signal. Beacon blinks green.




Stopped, no errors (ready)

Entire light disc on each side pulses blue slowly (0.25 Hz). Beacon is steady green.




Driving with Warning (doesn't prevent driving, such as low battery)

The Light Discs will be orange instead of blue for Stopped, Driving, and Turn Signals. Beacon alternates green then yellow.




Turn Signal with Warning (doesn't prevent driving, such as low battery)

Same as Turn Signals, but both the blue rotating arc and blinking segment are orange. The moving arc and the blinking segment have independent timing.




Driving Slowly, E-Stop Inactive

When driving under 300 mm/s, the LD does not generate E-Stop, however it still actively performs safety checking and successfully avoids obstacles. The pattern is essentially the same as driving, except the background blinks orange. The moving arc and the blinking segment have independent timing.




Stopped with Warning (such as low battery)

The light discs will be orange instead of blue for Stopped with Warning. Beacon alternates long green with short yellow.




Obstacle Detected

The Light Discs will blink yellow if the AIV is stopped for an object in its safety zone. Beacon blinks yellow.




Lost

When the AIV is lost, the Light Discs will each display two orange arcs, traveling from the 6 o'clock to the 12 o'clock position and back, in opposite directions. Beacon blinks yellow.



Charging

When docked, a green arc will indicate the current state of charge (SOC), showing steady green from the top of the disc to the current SOC. A small white arc travels back and forth between the two ends of the green arc. Beacon blinks green (red if E-Stopped).




Left Side	Right Side	State of Charge
0 to 90 cw	0 to 270 ccw	25%
0 to 180 cw	0 to 180 ccw	50%
0 to 270 cw	0 to 90 ccw	75%
full circle	full circle	100%

NOTE: The state of charge displayed is continuous, not limited to 25% increments.


E-Stop

The Light Discs will blink red in an E-Stop condition. Beacon blinks red.



Booting

When booting, the Light Discs will display two blue arcs, traveling from the 6 o'clock to the 12 o'clock position and back, in opposite directions. Beacon alternates green, yellow, then red.



In the following table:

- Blink indicates that a disc or light is on for a period, then off for a period.
- Pulse indicates a 0.25 Hz fade on and off.
- Circle indicates that the lights appear to be going in a circle.
- Half-circles indicates two arcs, moving opposite each other between the top and bottom.
- Solid indicates that a light is on continuously.
- Alt indicates that the beacon switches between different lights, with no pause. Two lights with Alt means one light is always on, but not two at once.

Table 7-1. Indicator Meanings

Light Disc		Beacon		Meaning
Color	Pattern	Color	Pattern	
Blue	Moving Circle	Green	Blink	Driving straight, all ok
Blue/ Orange @front	Moving Circle/ Blinking signal	Green	Blink	Turning > 30 degrees in direction of orange turn signal, all ok

Light Disc		Beacon		Meaning
Color	Pattern	Color	Pattern	
Blue	Pulse	Green	Solid	Stopped, all ok
Orange	Moving Circle	Green /Yellow	Alt	Drive with warning, doesn't prevent driving e.g. low battery
Orange/Orange @front	Moving Circle/ Blinking signal	Green /Yellow	Alt	Turn with warning
Blue/ Orange	Moving Circle/ Blinking signal	Green	Blink	Driving slowly, <300 mm/sec
Orange	Pulse	Green/Green/Green /Yellow	Alt	Stopped with warning
Yellow	Blink	Yellow	Blink	Object detected in safety zone
Orange	Left+Right Half-circles	Yellow	Blink	Lost
Green/White arc	Partial Circle/-moving small arc	Green normally, Red if E-Stopped	Blink	Charging
Red	Blink	Red	Blink	E-Stop, stops driving
Blue	Left+Right Half-circles	Green/Yellow/Red	Alt	Booting

LD Platform Core Indicators

The left end of the LD Platform core has 12 indicator lights.




Figure 7-15. Core Indicator Lights

The following table gives their meanings:

Indicator	Meaning
Left Column	
LOGIC	The microcontroller has power
PC	The LD Platform core and the servo controller are communicating
DRIVE	The drive wheels are under servo control
ESTOP	An E-Stop has been activated
Middle Column	
20V	20 V power is available
12V	12 V power is available
5V	5 V power is available
VBAT	Raw battery power is available
Right Column	
LAN MAINT	The Maintenance Ethernet connector is showing activity
LAN USER	The USER LAN connector is showing activity
WLAN	The WiFi is showing activity
HD	The hard drive is showing activity

Battery and Docking Station

For the battery, see Battery Indicators and Controls on page 134.

For the docking station, see Docking Station on page 135.

Chapter 8: Operation

Before proceeding, you need to have performed the steps covered in the Setup and Configuration chapters, so your platform has a map to work from.

8.1 Operating Environment

Intended Use

The LD Platform Cart Transporter is designed for operating in indoor industrial or professional environments. It must be deployed in a manner that takes into account potential risks to personnel and equipment. The product is not intended for use in uncontrolled areas without risk analysis, for example, areas open to general public access. Use in such areas may require deployment of additional safety measures.

Clearance

The LD Platform Cart Transporter is designed to operate in an environment that is level and has no doors or other restricted areas too narrow for the cart or transporter.

It is the user's responsibility to ensure that adequate clearance is maintained on each side of the AIV, so that a person cannot get trapped between the AIV and a wall or other fixed object. You should consult the applicable standards for your area.

An exception to side clearance can exist at pickup and drop off locations, where the AIV must get close to conveyors or other fixed objects.



CAUTION: PROPERTY DAMAGE RISK

Do not allow the AIV to drive through an opening that has an automatic gate or door unless the door and AIV are configured correctly with the Door Box option.

Refer to the *LD Platform Peripherals Guide* for details on the Call/Door Box.

Obstacles

If the AIV will be entering high-traffic areas, the user must take appropriate precautions to alert people in those areas that an AIV might enter. If the traffic consists of other machines, the user must adjust the AIV's and/or the other machine's parameters to reduce the risk of a collision.

Care must be taken to avoid:

- glass doors and walls
- pits without railings or low bumpers
- floors with access panels removed
- loose cables, hoses, etc.

This specifically includes wires hanging from above the AIV, which could pose a hazard if the AIV ran into them.

- large, highly-reflective objects

Environment and Floor

Floors must be level and provide good traction, typical of good walking conditions.

- Temperature 5 to 40°C (41 to 104°F)
- Humidity 5% to 95%, non-condensing
- Altitude Up to 1000 m above mean sea level

NOTE: Read the warning that follows step and gap traversal.
Any steps must have a smooth, rounded profile.

- Step traversal Up to 5 mm (0.2 inch) at 250 mm/s only
- Gap traversal Up to 5 mm (0.2 inch) at 250 mm/s only



CAUTION: PROPERTY DAMAGE RISK

The transporter with cart is designed and intended for smooth, level floors. While it is capable of driving over a step or gap as listed, frequent or high-speed driving over steps or gaps will shorten the lifespan of the drivetrain components.

NOTE: At less than the recommended speed, the LD Platform Cart Transporter may not be able to traverse the step height listed.

The LD Platform Cart Transporter is not intended for use in hazardous environments (explosive gas, water, dust, oil mist). It has an IP rating of IP20.

The LD Platform Cart Transporter is not intended for use in the presence of ionizing or non-ionizing radiation.

Platform Getting Stuck

It is possible, though not likely, for the platform to get into a position from which it cannot move without Operator assistance.

Some examples are shown in the following figure.

If the platform has to be lifted to be free to drive again, refer to Safety Measures Prior and After Maintenance on page 148.




Figure 8-1. Examples of the Platform or AIV Getting Stuck, (A) Platform Stuck Under Overhang, (B) AIV Option Stuck Under Overhang, (C) Driven off Ledge, and (D) Driven Over Excessive Gap

Cart Getting Stuck on Platform

To remove a cart that is stuck in the latched position:

1. Power off the cart transporter completely.
2. Press and hold the Unlatch button on the Operator panel until the transporter is fully unlatched. It should take about 5 seconds for the latch to start moving.

8.2 Typical Operation

During normal startup, your platform powers all its onboard systems¹ and runs its onboard software automatically to provide an application-ready AIV. If it has been given a map of its workspace and knows where it is within that environment (localized), your AIV is ready to perform on startup and will operate autonomously, without human intervention.

Paths are not pre-programmed, but instead are generated dynamically onboard the platform. Paths are updated many times per second to maintain a smooth trajectory and to account for any obstacles that are detected by the onboard sensors. Navigational parameters are stored onboard the platform, and can be viewed and modified using the MobilePlanner software, which is covered in the *Mobile Robot Software Suite User's Guide*.

¹As configured either by the factory or through your own parameter changes.

The MobilePlanner application, running on your computer, is used to configure the many high-level operating characteristics of the platform, including speeds and accelerations, sensor safety zones, minimum battery level allowed before docking for recharging, which map to use, and many other parameters. The MobilePlanner software typically communicates with the platform over the wireless network. A direct connection, through the Maintenance Ethernet port on the platform, is also possible.

IMPORTANT: The Operator Mode of the MobilePlanner software, which does not require a license to run, should be protected with user ID and password access, to prevent unauthorized operation of an AIV.

8.3 Power and Charging

The platform battery supplies ample power for the motors, electronics, and accessories.

The platform ships separately from the battery. The battery is shipped at less than 30% charge, to comply with air-shipping regulations. You should have installed the battery in the platform in Installing the Battery on page 45. You should fully-charge it as soon as possible, to avoid battery damage from a full discharge.

Battery recharging is typically managed by the platform. With ample power, as is provided by the automated docking station, all onboard systems function continuously while the battery recharges.

The Operator screen shows % state-of-charge (SOC) remaining for battery.

Run-time, with no load, is approximately 15 hours. This will vary significantly depending on operating conditions.

Recharge time is approximately 4 hours.

Battery Indicators and Controls

The battery has (from left to right) one red/green bi-color and three green LEDs, and one push-button (labeled SHOW LEVEL). The firmware blinks LEDs 1 through 4, back and forth, one at a time. From left to right, the LEDs indicate:

LED	Color	Meaning
1	Red	Error condition ^a
	Green	25% state of charge ^b
2	Green	50% state of charge
3	Green	75% state of charge
4	Green	100% state of charge ^c
a:	If the red light blinks after pressing the SHOW LEVEL button, the battery is depleted and needs a recharge. If the red light blinks constantly, the battery needs service. Connecting the battery to a platform will write an error code to the log, which will allow Service to better troubleshoot the problem.	
b:	While powered up, the LEDs blink back and forth from 1-4.	

LED	Color	Meaning
c:		When on the docking station, the right-most LED blinks when the battery the pack is balancing. When the battery is full and balancing is complete, all LEDs light solid.




Figure 8-2. (A) Battery LEDs and Push-Button (Show Level), (B) Power Cable, and (C) Data Cable

Pushing the “SHOW LEVEL” button displays its state of charge. This can be useful when a battery is in storage, and you want to know its state of charge.

NOTE: After pressing the SHOW LEVEL push button, the battery will light all LEDs for a brief time, then blinks the LEDs back and forth one LED at a time, up to the LED representing the current state of charge. It will continue doing this for 4 hours, until it powers itself off. To turn off this display manually, press and hold the push button for 10 seconds.

Docking Station

The automated docking station is both a manual and an automated means for recharging your platform battery.

Autonomous Charging

During normal, autonomous operation, the AIV manages charging automatically through the automated docking station. The AIV approaches the docking station frontward, and then turns around and backs onto the docking station to charge. There is about a 10-second delay between when an AIV docks and the charging LED turns on.

Connecting and disconnecting the AIV with network and onboard clients will not disturb the charging state (though moving the AIV will, of course). The station supplies ample power for all onboard systems while charging its battery, so you can continue operating those systems while charging.

If the AIV is powered off, it will turn on automatically when pushed onto the docking station. The robots can be turned off while on the docking station. If the robot is turned off, it must be removed from the docking station to be started.



Figure 8-3. Docking Station

Indicators, Controls, and Connections

The docking station has a power switch and two LEDs:

- blue indicates that power is available.
- yellow indicates that a charge is in progress.

The power switch, located on the right side of the dock, has an integrated thermal fuse, which can shut down the dock if it becomes too hot. If this happens, you have to wait for the fuse to cool down, toggle the switch to off (0) and then back to on (1).

The power plug for AC supply is next to the power switch. Power requirements are 100-240 VAC, 50-60 Hz, and 8 A.

The plug for connecting the manual charging cable is on the left side of the station, as viewed from the front.

Environmental Requirements

- Ambient temperature range: 5 to 40°C (41 to 104°F)
- Humidity: 5% to 95% non-condensing

Maintenance

The docking station contacts should be cleaned quarterly with isopropyl alcohol. See Docking Station Contacts on page 156.

The guide roller can be replaced in the field. See Docking Station Roller and Bearing on page 166.

If necessary, the height of the docking station contacts can be adjusted. See Docking Station Contact Adjustment on page 54.

Manually Charging the Battery

Battery in Platform

To manually charge a battery inside the platform, push the platform backwards, with E-STOP engaged, so that the rear of the platform slides over the contacts of the docking station.

There is about a 10-s delay between when the platform is in position and when the charging LED turns on.

NOTE: You will need to press and hold the brake release button before moving the platform.

NOTE: If you push the platform too far onto the docking station, it will not charge. Make sure that the yellow charge light comes on and stays on.

Standalone Battery

The battery can be charged, outside of the platform, by using the connector on the left side of the docking station (viewed from the front) with the provided charging cable. This will most likely be used for charging a spare battery, while a second battery is still in the platform, and the platform is in use. Some users choose to manually charge a spare battery, and swap that for the battery inside the platform.

There is about a 10-s delay between when you connect the battery cable and when the charging LED turns on.

NOTE: The docking station cannot charge a platform and a separate battery at the same time. If a platform is on the station, the power to the manual charge connector is cut off.

Balancing the Battery

The platform battery is composed of multiple cells, which need to stay balanced in order to maintain maximum run-time.

There are three ways for managing battery balancing:

- Set the platform's DockUntilDoneCharging parameter to True. In this case, the battery will balance before saying it's done charging, so the battery will get balanced every time the platform docks. You do not have to do anything extra to balance the battery.

In this mode, the battery will typically take about 10 minutes to balance after charging.

NOTE: This is the mode that is recommended for platforms that aren't doing battery swapping.

- Exchange the in-service battery, periodically, with a fully-charged spare battery.

A spare battery that remains plugged into a docking station will be balanced. In this mode, you don't have to worry about battery balancing, although it does add the task of manually swapping batteries.

The interval between battery swaps depends on how the AIV is used. This includes the weight it carries, and what percent of the time it is in service. You will need to determine the best interval for your situation. Swapping the battery at every shift change is a commonly-used interval.

NOTE: This is the mode that is recommended for battery swapping, if you are not charging the battery while it is inside the platform.

- Set the platform's DockUntilDoneCharging parameter to False, to let the platform get a partial charge by docking. The StateOfChargeToChargeTo and MinutesToChargeFor parameters need to be set to appropriate (non-zero) values. You would then do a battery swap with a fully-charged and balanced battery periodically, such as once a week.

- StateOfChargeToChargeTo determines the state of charge the battery needs to attain before the platform can stop charging.

A 90% value here would get the battery mostly charged, but not balanced.

- MinutesToChargeFor determines the number of minutes the battery needs to charge before the platform can stop charging.

The platform will stop charging when the battery reaches either of these parameter values.

NOTE: If both of these parameters are left at the default of 0, and DockUntilDoneCharging is set to False, the platform will dock, and never undock.

We recommend that you do a battery swap weekly, at a minimum. If you see a reduction in run-time, you should do a swap more often than that.

NOTE: The longer you wait to balance a battery, the longer it will take to balance. A battery that is badly out of balance can take well over 10 hours to balance after charging.

8.4 Startup

Procedure

Press and hold the ON button for 0.5 s, then release. It takes about a minute for all the systems to start up and make their various interconnections. If the platform doesn't start up, try power OFF, check your connections, and then power ON.

Startup is complete when the Light Discs stop indicating boot (two blue light segments, moving in opposite directions from 6 o'clock to 12 o'clock and back).

Joystick

The joystick lets you quickly move the platform to its destination. This can be used to drive it from the shipping dock to an automated docking station.

IMPORTANT: The joystick should be locked up when not in use, to prevent unauthorized operation of an AIV.




Figure 8-4. Joystick, (A) Speed Control, (B) Goal Button, (C) Directional Control, and (D) Trigger

The joystick plugs into the left side of the platform, under the small access panel at the upper right corner of the platform. (The Maintenance Ethernet port is also there.) The access panel is held in place with a push-push latch, and retained by a lanyard.



CAUTION: PERSONAL INJURY OR PROPERTY DAMAGE RISK

The platform safety scanning laser is not tied into the E-Stop chain when driven using the joystick. The Operator should maintain control of the joystick and the AIV whenever the joystick is connected to the AIV.

Joystick Use

Use the joystick to drive the platform manually. Squeeze the trigger to enable the drive button.

Push the drive button forward or back to make the platform move in that direction. Push the drive button to the side to make the platform rotate in that direction. Diagonal positions of the drive button move the platform in an arc.

The platform slows to a stop when you release the trigger. To stop more quickly, continue to squeeze the trigger and pull or push the drive button to its limit in the opposite direction of the platform's travel.

8.5 Working with Carts

Goals

The parking goals and the LD Platform Cart Transporters need to be set up in the MobilePlanner software. Refer to Configuration on page 61 for details on MobilePlanner configuration, and see the *Mobile Robot Software Suite User's Guide*.

Operation

The transporter locates the cart, couples with it, transports it to the dropoff goal, and uncouples from the cart, leaving the cart at the dropoff goal while it proceeds to its next assigned job.

Cart-Locating

If a cart is at a parking goal, the transporter can navigate close enough to the cart for the Latching Mechanism to take over.

The Latching Mechanism pulls the transporter and cart together, which enables a sensor to detect that they are fully-coupled. Once the coupling sensor is triggered, the transporter will be able to move the cart.



CAUTION: PINCH RISK

The latch on the transporter can pinch you if you are not careful. Keep your hands clear of the Latching Mechanism when it is in action.



CAUTION: PINCH RISK

The coupling action of transporter and cart can pinch you if you are not careful. Keep your hands clear of the space between the HMI post and cart when the platform and cart are coupling.

NOTE: If the sensor does not get triggered, the transporter's software will prevent it from moving.

Cart Brakes

The two rear casters of the cart have brakes, which push a blunt pin against the caster rolling surface to prevent a cart from rolling when it is parked on a floor that is not perfectly level.

Cart brakes are only intended to prevent rolling on a slightly unlevel floor. They will not immediately stop a moving cart, or prevent a cart from rolling down a slope.

Although it is possible to push the cart with the brakes engaged, this is not recommended because it will accelerate wear of both the braking pins and the casters themselves. When a

cart needs to be moved, the Operator should always release the brakes with the brake release handle.

In the unlikely event that the cart becomes unlatched from the platform while in motion, the brakes are designed to stop the cart within six feet.

Automatic Brake Release

When the transporter couples with the cart, it actuates a lever that releases the cart brakes, so the cart can move freely with the transporter.

Manual Brake Release

When there is no transporter present, the cart brakes can be released manually. Each cart comes with a release cable and lever, similar to a bicycle brake handle, that releases the cart brakes when squeezed. Installation of this cable and lever is covered in Installing the Cart Brake Release on page 54. As long as the brake release handle is squeezed, the brakes will be released.

Chapter 9: Options

The LD Platform Cart Transporter is available with a number of options to enhance its performance and abilities.

Enterprise Manager

The Enterprise Manager manages a fleet of AIVs, for multi-AIV coordination and job management. It includes the Enterprise Manager appliance running the Mobile Software suite.

It is covered in the *Enterprise Manager user's guide*.

MobilePlanner Software (licensed)

In order to have your LD Platform Cart Transporter perform autonomous mobile activities, you need to make a map of its operating space, and configure its operating parameters. The MobilePlanner software is used to make this map and perform this configuration.

Refer to the separate *Mobile Robot Software Suite User's Guide* for details on how to map a working space and prepare the virtual elements, goals, routes, and tasks for your application.

The MobilePlanner software requires a license to run. You need at least one MobilePlanner license for each fleet of AIVs. Once a map is generated, it can be shared with multiple AIVs working in the same space.

Joystick

This is mainly used to drive the platform when doing a scan, in preparation for making a map of the workspace. You need at least one joystick for each fleet of AIVs. Once a map is generated, it can be shared with multiple AIVs working in the same space.

Spare Battery

At least one spare battery is needed if you opt to swap the platform's battery, rather than having it charge itself at a docking station. See *Manually Charging the Battery* on page 137.

Spare Carts

Extra carts can be ordered, because a cart installation can use more carts than transporters.

The part number is 75020-000.

The following options are documented in the LD Platform Peripherals Guide.

Call Buttons/Door Boxes

Call buttons are used to issue a request for an AIV to go to the goal associated with the button. There may be multiple call buttons, even in an installation where there is only one transporter.

Door Boxes are used to open an automated door, so the AIV can pass through.

See *LD Platform Peripherals Guide*.

Acuity Localization

Acuity localization uses an upward-facing camera to localize the platform using overhead lights, which it compares with lights stored in its map. This can be used in circumstances where laser localization is difficult, either because the environment has too many changing features or simply not enough features for laser localization. If there are many objects, such as pallets or carts, which change location frequently, they may not be on the platform's map, and may also block the laser's view of features that are on the map. In such cases, Acuity localization may be a better choice than using the safety scanning laser for localization.




Figure 9-1. Acuity Parts

Callout	Description	Callout	Description
A	Foam Dust Seal	F	Bracket
B	NOTE: Top ND filter not shown.	G	Direction of Travel label
C	Tube	H	M4 x 12 screws go up through base
D	Camera	J	Base
E	Camera mounting screws		

High-Accuracy Positioning System

This allows an AIV to achieve accurate alignment at a specific location, typically at a fixed conveyor, using a sensor to detect magnetic tape at that location.

Chapter 10: Maintenance

This chapter covers periodic maintenance and user-serviceable parts replacement for the LD Platform Cart Transporter.




Figure 10-1. Major LD Platform Cart Transporter System Parts, with Acuity Camera

Callout	Description	Callout	Description
A	Operator Panel	G	Rear-facing Laser, Guard
B	Side Lasers, Guard x2	H	Light Disc x2
C	Laser Support Tube x2	J	Rear Sonar
D	Brace x2	K	Battery Cover
E	Navigation Laser	L	HMI post
F	Low Front Laser		




Figure 10-2. Top View of an LD Platform Cart Transporter, Side Laser Support Tubes Removed

Callout	Description	Callout	Description
A	HMI Pose Base	H	E-Stop, Latch, Unlatch
B	Top Plate	J	Light Pole (Beacon)
C	Coupling Laser Cover	K	Touchscreen
D	Latch Position Sensor	L	On/off/Brake/Key Switch
E	Latching Mechanism Cover	M	Operator Panel
F	HMI Post	N	Rear-facing Laser
G	Antenna x2	O	Car Latch




Figure 10-3. Location of Parts in the Payload Bay

Callout	Description	Callout	Description
A	Platform Core	C	Core Mounting Bracket
B	Platform Sonar Controller	D	Payload Bay

10.1 Safety Aspects While Performing Maintenance

IMPORTANT: Only skilled or instructed persons, as defined in the Mobile Robot LD Safety Guide, should perform the procedures and replacement of parts covered in this section.

Electrical Hazards



WARNING: ELECTROCUTION RISK

During maintenance and repair, the power to the docking station must be turned off. Remove and lock up the power cord to prevent unauthorized third parties from turning on power. The access covers on the docking station are not interlocked.



WARNING: ELECTROCUTION RISK

There are no user-serviceable parts inside the docking station. Do not remove the covers of the docking station. There is high voltage inside, and the covers are not interlocked.



CAUTION: SHOCK RISK

During maintenance and repair of the transporter, turn off the transporter and disconnect the battery as soon as possible. Avoid shorting the terminals of the battery.

Burn Hazard



CAUTION: BURN RISK

Parts of the drivetrain can get hot during operation. Allow the platform to cool down before servicing.

Pinch Hazard

Platform Covers



CAUTION: PINCH RISK

The covers are held in place with strong magnets, which can pinch you if you are not careful. Follow the instructions in the Maintenance chapter for handling covers.

Magnetic Field Hazards

Platform Covers



WARNING: MAGNETIC FIELD - MEDICAL IMPLANT RISK
Magnetic fields can be hazardous to medical implant wearers. Medical implant wearers stay back 30 cm (12 inches) from the covers, which are held in place with strong magnets.

Docking Funnel



WARNING: MAGNETIC FIELD - MEDICAL IMPLANT RISK
Magnetic fields can be hazardous to medical implant wearers. Medical implant wearers stay back 30 cm (12 inches) from the underside of the platform, which is exposed during certain maintenance procedures for which the platform is tipped on its side.

10.2 Safety Measures Prior and After Maintenance

Prior to performing maintenance work (safety inspection, cleaning, removing parts, installing parts, etc.), following safety measures must be taken:

- Ensure that the AIV has come to a complete stop, by pressing the E-Stop button on the Operator Panel
- Power OFF the AIV by pressing the OFF button on the Operator Panel

Once maintenance work has completed, and the AIV is ready for use, take following actions:

- Power ON the AIV by pressing the ON button on the Operator Panel
- Release the E-Stop

10.3 Lifting the Platform Safely

If, for any reason, you need to lift the platform by hand, take care to lift from safe lifting points.



WARNING: PROPERTY DAMAGE RISK
Lifting the platform from the wrong points can damage the platform.

Front Lifting Points

On each side of the laser, under the upper side of the laser slot. Do not lift at the center - there is no frame supporting it there. Do not lift anywhere else! Refer to the following illustration:




Figure 10-4. The Upper Surface of the Laser Slot. (A) Lift Here Only, and (B) No Lift

Rear Lifting Area

The center underside of the platform, where the cover has a raised section. Do not lift anywhere else! Refer to the following illustration:




Figure 10-5. Bottom of Battery Door Skin. (A) Lift Here

10.4 Safety Inspection

Item	Period	Reference
Warning Devices	1 week	Warning Devices on page 150
Warning Labels	1 week	Warning Labels on page 150
Informative Labels	1 week	Informative Labels on page 153

Warning Devices

The following warning devices should be inspected for proper function on a weekly basis.

Light Discs

The light discs on each side of the transporter should be checked.

Flashing Light(s)

The beacon on top of the HMI post should be checked.

If there is a user-installed beacon or light tower that has been installed to warn people of the AIV's movement or imminent movement, it should be checked for proper function every week.

You should ensure that the light remains visible under all operating conditions, so that, regardless of your payload structure design, any people near the AIV can see it.

Buzzer

The warning buzzer should be checked for proper function. In order to maintain conformity with applicable standards, it is important that the buzzer be audible in all operating conditions and environments.

Warning Labels

See Figure 10-6. and Figure 10-7.

All warning labels on the LD Platform Cart Transporter should be checked on a weekly basis for being present and legible. If any of the labels are missing or illegible, they should be replaced. The labels, with part numbers, are:

- Invisible Laser Aperture Label, 13307-000L



One of these labels will be on the front navigation laser.

- Laser Aperture Label, 13308-000L



One of these labels will be on each of these lasers:

- Low Front laser
 - Left and Right Side lasers
 - Rear laser
 - Coupling laser
- Pinch Point Label, 12992-000



A pinch point label is on top of the latch mechanism cover.

- Hand-entanglement Label, 18180-000



A hand entanglement label is under the latch mechanism cover, near the belt and pulley. See Removing Latching Mechanism Cover on page 156 for instructions on removing the cover.

- Medical Implant, Magnetic Field Warning Label, 18621-000



One magnetic field/implant label is on the transporter rear cover.

A second is on the top rear bar of the cart.

A third is on the underside of the transporter, on the docking funnel. This magnet is only exposed during maintenance, when the transporter is tipped on its side.

- Yellow circle surrounding the E-Stop, 11229-167

This is labeled EMERGENCY STOP. It is located on the Operator Panel, at the top of the HMI post.

- No Riding Label, 18178-000



One of these labels is located on the LD Platform Cart Transporter top plate, near the front.


Another is on the top rear bar of the cart.

- No Incline Label, 18179-000



A no incline label is attached on the top plate of the transporter, in front and to the side of the plastic triangle for aligning with a cart.

- Automatic Vehicle Label, 18623-000



An Automatic Vehicle label is attached to the rear cover of the LD Platform Cart Transporter.

Informative Labels

The following labels are on the Operator Panel, at the top of the HMI post. They should be checked on a weekly basis for being present and legible. If any of the labels are missing or illegible, they should be replaced. The labels, with part numbers, are:

- HMI post button label, 14463-000
This includes the BRAKE, ON, OFF, and Keyswitch labels.
- HMI post LATCH, UNLATCH button labels, 14628-000




Figure 10-6. Locations of Labels on LD Platform Cart Transporter

Callout	Description	Callout	Description
A	Pinch Hazard Label	F	E-Stop Button

B	Hand-Entanglement Label (under cover)	G	On, Off, Brake Labels
C	No Ride and No Incline Labels	H	Magnetic Field Labels
D	Laser Labels	I	(Underside of Platform)
E	Latch, Unlatch Labels		



Figure 10-7. Magnetic Field/Implant, and No Riding Labels on Cart

Callout	Description	Callout	Description
A	Magnetic Field and No-ride Labels	B	6 mm diameter (0.25 in.) Pass-through hole for brake cable, through rear frame tube

10.5 Cleaning

Work Area Maintenance

The work area of the AIVs must be kept generally clean and free from clutter that could block an AIV.

Anything spilled on the floor of the work area, such as dust, ice, pooled water, etc., must be removed immediately, as this would interfere with the AIV's ability to drive safely, as well as navigate. Any substance that reduces the AIV's traction with the floor will impair its ability to drive, stop, turn, and navigate. Pay particular attention to areas around goals and frequently-traveled paths.

LD Platform Cart Transporter and Cart

Some parts of the LD Platform Cart Transporter require periodic cleaning. The following table gives a summary of cleaning procedures for the LD Platform Cart Transporter system.

Table 10-1. *Cleaning*

Item	Period	Reference
Clean docking station contacts	3 months	Docking Station Contacts on page 156
Clean axles and tires	As needed	Tires on page 155
Clean casters	As needed	Casters on page 155
Clean all laser lenses - wipe clean	6 months/ as needed	Lasers on page 155
NOTE: The safety scanning laser will display a flashing icon of a windshield and wiper when it detects that its lens needs cleaning.		

NOTE: When the tires or floor get dirty, the wheels will tend to slip, and the AIV can fail to localize. This is common near goals. Both the floor and the tires need to be kept clean.

NOTE: The frequency of these procedures will depend on your particular system, its operating environment, and the amount of usage. Operating in an environment with a lot of dust or dirt will require more frequent cleaning. Use the intervals in this section as guidelines, and modify the schedule as needed.

Tires

Occasionally clean the tires with a mild soapy solution. Remove any dirt or debris that may accumulate on the tires, because these can degrade the AIV's performance.

Casters

Occasionally clean the casters with a mild soapy solution. Remove any dirt or debris that may accumulate on them, because these can degrade the AIV's performance.

This applies to the casters on the LD Platform Cart Transporter as well as on the cart.

Axles

Keep the axles free of hair, string, or anything that may wrap around and bind up the platform's drive.

Lasers

Occasionally clean the lenses of all lasers. Use only alcohol-based, non-abrasive cleaners, and wipe thoroughly.

Docking Station Contacts

The two docking station contacts occasionally need to be cleaned. The suggested interval is 3-6 months, depending on frequency of charging.



WARNING: ELECTROCUTION RISK

Unplug power from the docking station before cleaning. Remove the power cord at the docking station.

Clean the contacts with isopropyl alcohol.



CAUTION: PROPERTY DAMAGE RISK

Do not lubricate the docking station paddle. Lubrication will reduce the life of the paddle.

10.6 Accessing the Payload Bay

The payload bay is the area between the platform top plate and the top of the platform itself. Care must be taken, when accessing the payload bay, that the wires and connections between the platform and the HMI post and coupling plate are not damaged. See Top View of an LD Platform Cart Transporter, Side Laser Support Tubes Removed on page 146.

The top plate is held on with eight M6 socket-head screws and two M5 cap screws. You should not remove the HMI post base. The sheet metal cover of the Latching Mechanism needs to be removed to access the two M5 screws. The top plate and the rest of the coupling plate will come off together.



CAUTION: PROPERTY DAMAGE RISK

When lifting the top plate off, take extra care not to scratch the coupling laser's lens with the top plate itself.

Removing Latching Mechanism Cover

1. Remove the four M3 screws holding the Latching Mechanism cover to the top plate.
These go into four 45 mm standoffs in the top plate.
Retain the M3 screws for reassembly.
2. Lift off the Latching Mechanism cover.
Retain the cover for reassembly.

Removing Top Plate

1. Remove the two stainless M5 screws that were covered by the Latching Mechanism cover.
Retain the M5 screws for reassembly. These are socket-head cap screws.
2. Remove the eight M6 screws along the sides and front of the top plate.

Retain the M6 screws for reassembly. These are flat head, stainless screws.

3. Disconnect the cables going to the latching assembly and sensors in the Latching Mechanism.
4. Carefully lift off the top plate.

As you remove the top plate:



CAUTION: PROPERTY DAMAGE RISK

Take care not to scratch the laser lens when removing the top plate.

At this point, you will have access to the payload bay.

Installing Top Plate

1. Reinstall the top plate.



CAUTION: PROPERTY DAMAGE RISK

Take care not to scratch the laser lens when reinstalling the top plate.

2. Reconnect the cabling to the latching motor assembly and its sensors.
3. Reinstall the eight M6 screws along the sides and front of the top plate.
Use the screws previously removed from the top plate.
4. Reinstall the two M5 screws that were covered by the Latching Mechanism cover.
Use the screws previously removed from the top plate.

Installing Latching Mechanism Cover

1. Place the Latching Mechanism cover back onto the top plate.
2. Reinstall the four M3 screws holding the Latching Mechanism cover to the top plate.
Use the screws previously removed from the Latching Mechanism cover.
These go into four 45 mm standoffs in the top plate.

10.7 Removing and Installing LD Platform Cart Transporter Covers

Many of the maintenance procedures require removing some of the platform's covers. Most covers are held in place with just magnets. The rear outer cover has an additional brace at the bottom for support, the bumper cover uses screws and magnets, and the access panel uses just a push-push (toggle) latch.




Figure 10-8. LD Platform OEM Skins

Callout	Description
A	Access Panel - covers the maintenance Ethernet port and joystick connector.
B	Left side skin - covers the LD left drive train.
C	Right side skin - covers the LD right drive train. NOTE: Both side skins hold a light disc and cover.
D	Battery door skin - covers the battery access door.
E	Rear skin - covers the LD rear components, and houses the sonar transducer pairs.
F	Front upper skin - Above the safety scanning laser and speakers.
G	Bumper - Above the lower bumper assembly and low front laser.

With the exception of the bumper, no tools are needed for either the removal or installation of the platform's skins.



CAUTION: PINCH RISK

The magnets holding the covers in place are strong enough to pinch you if you are not careful.

Additional Information: In general, it is better to install the payload structure before installing the skins.

The covers are:

- Rear Inner (Battery)
- Access Panel
- Left Side, Right Side
- Both side covers include a light disc and cover.
- Front Upper
- Bumper
- Rear Outer

With the exception of the bumper cover, no tools are needed for either the removal or installation of the covers.

Removing Covers

NOTE: After removing covers, place them inner-side down, so the outer surfaces don't get scratched.

The covers can be removed in the order in which they are listed above.

- The rear outer must wait for the rear inner and the two side covers.
- The front upper must wait for the two side covers.
- The two sides, the rear inner, and the bumper cover can all be removed without removing any other covers, except that the left cover must wait for the access panel.

NOTE: The light disc covers are not covered here because they are only removed from the side covers to replace one of the light disc controllers.

Rear Inner Cover (Battery)

This provides access to the battery compartment door.

1. Pull the bottom of the cover away from the platform chassis.
This is easiest if you grip it with two hands, toward the center.
2. Lower the cover down, so its top tab slides down, and clears the rear outer cover.

Access Panel

This provides access to the Maintenance Ethernet and the Joystick ports.

1. Push the left (front) side of the panel in, and the latch will release it.
Pushing the panel a second time will engage the latch.
2. When released, pull the left side out, and slide the panel to the left.
The panel is attached with a lanyard, to prevent getting lost.

You will need to place this panel out of the way when removing the left side cover.

Side Covers

1. For the left side cover, put the access panel out of the way.
2. Pull the bottom of the cover, at both sides, away from the chassis.
3. Work your way up the edges of the cover, pulling it away from the chassis as you go.
4. Remove the cover a few inches from the chassis.
The light disc wires plug into connectors on the inner side of each side cover.
5. Unplug the light disc connector, and move the side cover away from the platform.

Repeat for the other side cover.

Front Upper Cover

This cover is held onto the chassis the most tightly of any of the covers.

1. Grip the cover at the two outer edges.
2. Pry the cover away from the chassis.

Bumper Cover

This is the only cover that requires tools to remove.

1. Remove the screws at the sides of the cover.

Retain the screws for reinstalling the bumper cover.

2. Pull the cover off of the bumper.

It is held on with magnets, as well as screws.

Rear Outer Cover

This cover houses the two rear sonar pairs, which must be disconnected once the cover is part-way off the chassis. Each pair consists of one emitter and one receiver.

1. Pull the top of the cover away from the chassis a few inches.

The cover will pivot on the metal brace at its bottom edge.

2. Pull the four sonar wires, with their connectors, out of the chassis holes.

Refer to the following two figures.



Figure 10-9. Sonar Leads, with Connectors Still in Chassis

3. Unscrew all four sonar connectors.

Ensure that both sides of all connectors are labeled, and match. If not, label them.




Figure 10-10. Sonar Connectors, with Connectors Exposed

4. Tilt the cover down to about 45°, and slide the brace on the bottom of the cover out of its clip.

This will separate two pairs of magnets, so you will feel some resistance at first.

Installing Covers

The covers can be installed in the reverse of the order in which they are listed above.

- The front upper and rear outer covers must be installed first and second.
- The access panel must wait for the left side cover.

Bumper Cover

This is the only cover that requires tools to install.

1. Place the cover on the bumper.
It is held on with magnets, as well as screws.
2. Install the screws, removed during the cover removal, at the sides of the cover.

Front Upper Cover

1. Grip the cover at the two outer edges.
2. Align the bottom edge of the cover so it slides under the chassis support.
3. Tilt the top of the cover into position.

Rear Outer Cover

Because this cover houses the rear sonar units, they must be reconnected once the metal brace across the bottom is in the clip just below the battery access door.

1. Slide the metal brace into the clip in the chassis.

Watch the two magnets on the bottom of the cover, to align them with their mating magnets on the chassis. This is your best guide for getting this cover in its proper place.

These are inboard of the clip holding the brace, so you will have to look on each side of the cover to check their alignment.

2. When the magnets at the bottom are lined up, tilt the cover up to within a few inches of the chassis.
3. Pull the sonar connectors clear of the chassis, if they are not already out.

See the preceding figure.

4. Screw the four sonar connectors to their corresponding sonar leads.

Ensure that the labels for the connectors and leads match.

5. Tuck the connectors into the four holes in the chassis, until just an inch of sonar lead is sticking out.
6. Tilt the top of the cover up to meet the chassis.

Side Covers

1. Move the cover to within a few inches of the chassis, and plug in the light disc connector.

The light disc connector is accessible on the inner side of the side cover.

2. Place the top edge of the cover on the chassis, so the magnets hold it there.

Make sure the gaps on each side of the cover are the same width.

3. Tilt the bottom edge of the cover down.

4. Check each side of the cover to ensure that the cover edges on each side of the gap stick out the same amount from the chassis.

This is most likely to be uneven near the top of the cover.

5. If either edge sticks out more than the neighboring cover, pull the neighboring cover away from the side cover slightly, and release.

This should allow the side cover to snap into place, so both sides of the gap stick out the same amount.

Repeat for the other side cover.



Figure 10-11. Right Side Cover, Showing Even Gaps at Edges

NOTE: The gaps between the side covers and the bumper cover will be smaller than the other gaps, and will not be even.

Access Panel

1. Slide the panel to the right, so its tab goes under the left side cover.

The panel is attached with a lanyard, to prevent getting lost.

2. Press the left (front) side of the panel in, and the latch will hold it.

This is a toggle latch - pressing it once engages it, pressing it a second time releases it.

Rear Inner (Battery) Cover

1. Slide the cover up, so its top tab fits under the rear outer cover.



CAUTION: PINCH RISK

This cover is the most likely to pinch you if you are not careful, particularly at its bottom edge. Hold the cover at the bottom, in the center, with two hands.

2. Holding the cover near the center, with both hands, tilt the bottom of the cover down, towards the platform chassis.

10.8 Replacing Periodic Parts

The drive motors and gearbox are sealed and permanently lubricated, so they do not require periodic maintenance.

Maintaining and Replacing Batteries

Maintaining Batteries

- Every six months, inspect batteries (both stored and in-use) for damage or leaks.

If a battery is found to be leaking, do not expose it to water. If possible, submerge it in mineral oil.

Contact your local Omron support immediately for disposal instructions.

- Store batteries fully charged and upright at (one month) +5 to 45°C (41 to 113°F); (one year) 20 to 25°C (68 to 77°F).
- Every six months, charge stored batteries to a full charge.

Battery Replacement

The battery is expected to last for approximately 2000 recharge cycles.

NOTE: There are no serviceable parts inside the battery case. Do not open it.

IMPORTANT: Replace the battery only with an Omron Adept Technologies, Inc. battery.

Dispose of the battery according to all local and national environmental regulations regarding electronic components. Contact your local Omron support



CAUTION: PROPERTY DAMAGE RISK

Follow appropriate ESD procedures during the removal/replacement phases.

Removal



WARNING: PERSONAL INJURY RISK

The battery is heavy (19 kg/42 lbs). Observe safe lifting practices when removing or installing the battery.

1. Remove the inner rear platform cover.
 - a. Pull the bottom of the cover away from the platform chassis.
This is easiest if you grip it with two hands, toward the center.
 - b. Lower the cover down, so its top tab clears the rear outer cover.
2. Unlatch and open the battery compartment door, at the back of the platform.

The battery compartment door is capable of being locked. You may need to unlock it before opening.

3. Disconnect the power and data cables before removing the battery.

See the following figure.




Figure 10-12. Battery Cable Connectors

4. Slide the battery back and out of the platform.

There is a hand grip at the front and the rear of the battery, to help you lift it.

Installation

Refer to Installing the Battery on page 45 for instructions on installing the battery.

10.9 Replacing Non-Periodic Parts

All of the following parts are replaced on an as-needed basis.

Docking Station Roller and Bearing



WARNING: ELECTROCUTION RISK

There are no user-serviceable parts inside the docking station. Do not remove the covers of the docking station. There is high voltage inside, and the covers are not interlocked.

The roller, which guides the platform onto the docking station, may be subject to wear after extended use. The time to replace the roller should be based on your visual inspection and judgment of when it is too worn. We do not specify a quantitative measure for this.

Refer to the following figure for the location of the roller.



WARNING: ELECTROCUTION RISK

Unplug power from the docking station before starting. Remove the power cord at the docking station.

The roller is held to the docking station with a shoulder bolt.

1. Remove the shoulder bolt from the center of the roller. Retain the shoulder bolt.
2. Remove the roller and bearing from the docking station.
3. Install the new roller and bearing, using the retained shoulder bolt.




Figure 10-13. (A) Docking Station Roller, and (B) Switch

Docking Station AC Power Fuse

NOTE: The current version of the docking station uses a thermal fuse, built into the power switch. There are no user-serviceable fuses.

NOTE: The following procedure applies only to legacy docking stations.

The only user-serviceable fuses are in the docking station. The two external AC fuses are located between the power switch and the AC power plug.

Symptoms: When the docking station is switched on, the blue power light does not come on. (Verify that the unit is plugged into AC power.)



WARNING: ELECTROCUTION RISK

Unplug power from the docking station before starting. Remove the power cord from the charger.

Remove the fuse assembly by squeezing the two tabs toward each other, and pulling it away from the docking station. See the following figure.



Figure 10-14. Docking Station Fuse

The fuses are available from the factory as P/N 02212-000L. Equivalent fuses are available generically. The fuses need to be 250 V, 10 A, and Time-lag. An example of a fuse that meets this is:

Littelfuse 0215010.XP, 5x20 mm cartridge type

Docking Station Internal Fuse

NOTE: The following procedure applies only to legacy docking stations. There are no user-serviceable fuses on the current docking station.

Symptoms: When the docking station is switched on, the blue power light does not come on, but the docking station can charge a battery manually.



WARNING: ELECTROCUTION RISK

Unplug power from the docking station before starting. The docking station cover is NOT interlocked. Remove the power cord at the charger.

1. Remove the ten screws from the back cover of the docking station.
Two of these are on the sides, near the bottom.



Figure 10-15. Docking Station Rear Cover Screws (8 of 10)

Retain the screws for reassembly.

2. Remove the rear cover of the docking station.
3. Locate the in-line fuse.

It will be near the top of the docking station, just to the right of the central terminal bar.

4. Remove the old fuse, and replace it with a new fuse.

The fuse is P/N 13091-000.

5. Reinstall the docking station rear cover, and secure with the ten screws previously removed.

Safety Scanning Laser

If the Safety Scanning Laser needs to be replaced, contact your local Omron support.

Obstacle Detection and Coupling Lasers

All of the lasers on the LD Platform Cart Transporter, other than the Safety Scanning Laser, are the same model laser. The front of these lasers have two LEDs. Green indicates ready status, flashing red indicates an error. No LEDs lit indicates no power.

These lasers come with an attached cable, about 0.3 m (12 inches) long, with a male M12 connector.

Rear Sonar Units

The platform's four rear sonar units can be replaced individually. All four sonar units are identical, although two are used as emitters and two as receivers, in pairs.

1. Remove the inner and outer rear covers from the platform. Refer to Removing and Installing LD Platform Cart Transporter Covers on page 158.
2. Unscrew the connection between the sonar cable and the sonar unit's lead.
Ensure that both the connectors and leads are labeled, and match. If not, label them.
3. Compress the two flat springs holding the sonar unit, and remove it from the cover.
Press the new sonar unit through the hole in the rear outer cover, from the outside.
4. Connect the sonar cable to the new sonar unit's lead.
5. Insert the new sonar unit through the hole in the rear outer cover.
6. Reinstall the rear covers.

Sonar Controller

The sonar controller is located in the payload bay.




Figure 10-16. (A) Sonar Controller, (B) Core

1. Move the payload structure out of the way, so you have access to the payload bay.
2. Locate the sonar controller.
The controller is at the front of the payload bay, screwed into the payload bay deck with two screws, and is plugged into the Sonar 1 connector on the core. This connector is not accessible from the payload bay, but does not need to be unplugged for this procedure.
3. Unscrew the controller from the payload bay deck by removing two screws.
Retain the screws for mounting the replacement controller.
4. Unplug the larger cable from the sonar controller.
Be careful not to let the cable end slip into the chassis.
5. Unplug the four sonar unit cables from the controller.

These are the smaller cables that go to the individual sonar units. Make sure these are labeled and tied up, so they can't slip into the chassis.

6. Connect the four sonar unit cables to the new controller.

Ensure that the cable labels match the controller labels.

7. Plug the larger cable into the new controller.
8. Screw the new controller to the payload bay deck, using the two screws removed from the old controller.
9. Reinstall the payload structure.
10. Dispose of the old controller according to local and national regulations concerning electronic components.

Cart Latching Mechanism



CAUTION: PROPERTY DAMAGE RISK

The latch mechanism belt adjustment is for Omron Adept Technologies, Inc. Field Service only. Changing the belt tension can lead to premature failure.

The acetal end of the Latching Mechanism is subject to wear, and may need replacement.

When the acetal on the cart Latching Mechanism has worn through a quarter of its original thickness, or when either of the two screws holding the acetal block in place becomes flush with the acetal block, the block needs to be replaced.




Figure 10-17. Cart Latch Mechanism with acetal block, Vertical Position

Callout	Description	Callout	Description
A	Latch Motor	D	Delrin Block

B	Belt	E	Cart Latch Hook
C	Pulley		

NOTE: The color of the acetal block may vary.



CAUTION: PINCH RISK

The latch of the LD Platform Cart Transporter can pinch you if you are not careful. Keep your hands clear of the Latching Mechanism when it is in action.



WARNING: ENTANGLEMENT RISK

The belt and pulley of the LD Platform Cart Transporter can entangle your hand during maintenance. Keep your hands clear of the belt and pulley when they are moving. This is only a hazard during maintenance of this part of the LD Platform Cart Transporter.

1. Remove the latching mechanism cover.

See Removing Latching Mechanism Cover on page 156.

2. Rotate the cart Latching Mechanism up on its pivot:

In order to replace the acetal block, the cart latch hook has to be rotated up to its vertical position. If the hook-lowering block shown in the following figure is removed, the latch hook will be pulled up to its vertical position.




Figure 10-18. Hook-lowering Block and Screws

Callout	Description	Callout	Description
A	Delrin Block	C	Hook-Lowering Block
B	Hook	D	Screws

- Remove the two screws holding the hook-lowering block in place.
Retain the screws for re-assembly.
 - Remove the block, allowing the latch hook to spring up.
Retain the block for re-assembly.
3. Unscrew the two screws holding the acetal block on the end of the latch hook.

These were installed with threadlocker.

Retain these screws for attaching the replacement acetal block.

4. Remove the acetal block, and replace it with the new block.
5. Attach the new acetal block with the two screws previously removed.
Use Loctite® 222MS (blue) on the screws.
6. Reinstall the hook-lowering block.
 - Manually lower the latch hook, and insert the block, which will keep the latch hook in the down position.
 - Insert the two screws previously removed to hold the hook-lowering block in place.
7. Reinstall the latching mechanism cover.
See Installing Latching Mechanism Cover on page 158.

Light Discs

The two light disc assemblies and their controllers are single units, so replacing a controller also replaces all of the lights on that side of the platform.

1. Remove the side cover, on the side that needs the light disc assembly replaced.
Refer to Removing and Installing LD Platform Cart Transporter Covers on page 158.
2. Unscrew the four screws holding the light disc PCA to the side cover.
Retain the screws and round cover for installing the new assembly.
3. Remove the light disc PCA.
4. Screw the new assembly and retained round cover to the side cover, using the screws retained from the old assembly. The PCA is keyed so that it can only be installed in one orientation.
5. Reinstall the side cover, connecting the cable to the new light disc PCA.
6. Dispose of the old light disc PCA according to local and national regulations concerning electronic components.

Operator Panel

The Operator panel will typically be located on a user-supplied payload structure, so the removal and replacement of this will vary from one AIV to another. It plugs into the HMI Panel connector on the core.

Wheels and Tires

The wheels and tires should be checked every 3 months. If they show signs of cracking, excessive wear, or any damage they should be replaced. Refer to the following figure.



Figure 10-19. Samples of Tire Wear

The wheels/tires are not user-serviceable parts. If the tires are worn or cracked, contact your Omron sales representative.

Drive Assemblies

The platform drive assemblies have been designed to be field-replaceable. This will replace the drive motor, gearbox, encoder, and wheel/tire assembly.

Removal

1. Remove the inner rear cover.
2. Unlatch and open the battery compartment door, at the back of the platform.
The battery compartment door is capable of being locked. You may need to unlock it before opening.
3. Disconnect battery power by unplugging the two cables at the rear of the battery.
4. Remove the side cover a small distance from the platform on the side where you want to replace the drive assembly. Refer to Removing and Installing LD Platform Cart Transporter Covers on page 158.

The light disc PCA cable will still be attached.

5. Disconnect the cable from the light disc PCA, so the side cover can be moved completely away from the platform.

This will expose the drive assembly.




Figure 10-20. LD Drive Assembly (arrow)

6. Lift the drive wheel up, compressing its springs, enough so that you can insert a $\text{Ø}6 \times 10 \text{ mm}$ (0.24 x 0.4 inch) pin into the hole on the rear side of the assembly (there is a hole on each side). This will keep the springs compressed (the wheel will be in the up position), and make removal easier. An M5 x 10 screw works well for this. If you saved the wheel pin, it should be used for this. See Figure 3-9. See also Chapter 10:




Figure 10-21. Spring-Compression Hole (arrow)

7. The drive assembly is held in place with three nuts on studs across the top, and two pairs of screws at each side, near the bottom of the assembly.

Remove the three nuts and four screws (and their washers) holding the drive assembly to the platform.

Retain these nuts, screws, and washers for attaching the new drive assembly.




Figure 10-22. Mounting Studs and Nuts at top of Drive Assembly




Figure 10-23. Mounting Screws at Bottom-Right of Drive Assembly

8. Remove the drive assembly from the platform.
The motor cable to the LD Platform core will still be attached.
9. Disconnect the motor cable at the drive assembly.

Installation

1. Lift the new drive wheel up, compressing its springs, enough so that you can insert a 6 x 10 mm (0.24 x 0.4 inch) pin into the hole on the rear side of the assembly (there is a hole on each side). This will keep the springs compressed (the wheel will be in the up position), and make installation easier. If you saved a wheel pin when you uncrated the platform, you can use that. An M5 x 10 screw also works well for this. See Maintenance on page 145.

NOTE: Make sure that the pin is short enough so that you can pull it out after the assembly is in place.

2. Connect the motor cable to the new drive assembly.
3. Install the new drive assembly over the three studs at the top of its bracket.

Use the nuts, screws, and washers you removed from the old drive assembly.

4. Remove the pin or screw you used to hold the wheel in the up position.
5. Put the side cover next to the platform, and attach the cable to the light disc PCA.
6. Reinstall the side cover.
7. Connect the battery power and data cables, and close the battery compartment door.
8. Reinstall the rear cover.

Platform Casters

The platform casters should be checked every 3 months. If they show signs of cracking, excessive wear, or any damage they should be replaced.

All four platform casters are identical, and are mounted to the platform in the same way.

NOTE: If you have a means of lifting the chassis of the platform enough to access the screw that holds on the caster, you can avoid removing the battery, which is only necessary to tilt the platform on its side.

If you cannot lift the chassis enough to access the caster screw:

1. Move the payload structure out of the way.

If the payload structure can be completely removed, do so. This enables you to tip the AIV on its side, so you have access to the casters underneath.

2. Remove the inner rear cover.
3. Unlatch and open the battery compartment door, at the back of the platform.

The battery compartment door is capable of being locked. You may need to unlock it before opening.

4. Disconnect the battery by unplugging the two cables at the rear of the battery.
5. Remove the battery from the platform.
6. Remove the side covers.
7. Lay the body of the platform on its side, exposing the casters.



WARNING: MAGNETIC FIELD - MEDICAL IMPLANT RISK

Magnetic fields can be hazardous to medical implant wearers. Medical implant wearers stay back 30 cm (12 inches) from the underside of the platform, which is exposed during this maintenance procedure when the platform is tipped on its side.

Whether or not you had to remove the battery:

1. Remove the M10 x 30 mm screw holding the caster to the platform.

The screw was installed with Loctite 263.

Retain the screw for attaching the new caster.




Figure 10-24. Platform Caster Replacement

Callout	Description
A	(4) M6 x 22 Screw, Flat Head Socket
B	Caster, Heavy Duty, with Bolt Hole Fitting
C	M10 x 30 mm Screw, Flat Head Socket
D	Use Loctite 263 on the M10 x 30 Screw
E	Completed Assembly

2. Remove the caster from the platform.
3. Put the new caster in place, and attach with the M10 x 30 mm screw you removed from the old caster.

Use Loctite 263.

Torque to 27 N·m (20 ft·lbf).

If you removed the battery for this procedure:

1. Return the platform to its upright position.
2. Reinstall the battery, connect the power and data cables, and close the battery compartment door.
3. Reinstall the inner rear cover.
4. Reinstall the side covers.

Cleaning Casters on ESD Platforms

Casters on the ESD platform are critical components as they provide the path to ground. As such, they require regular, periodic cleaning to preserve ESD protection capability.



CAUTION: PERSONAL INJURY OR PROPERTY DAMAGE RISK

This procedure requires placing the platform on its side. Unless you can do this safely with the payload attached, you will need to remove the payload.

You will need the following tools:

- Gloves
 - Wipes
 - Isopropyl Alcohol
 - Protective, supporting material on which to rest the platform (e.g., foam)
1. Remove the payload structure, if necessary.
 2. Remove the right and left side skins, and set them aside.
 3. Lift and pin the drive assemblies to more easily maneuver the platform. This puts entire robot weight on casters.
 4. Place the protective, supporting material on the right side of the platform. Using the right side prevents possible damage to the maintenance access panel.
 5. Carefully tilt the platform onto its right side onto the protective, supporting material.
 6. Use a wipe wetted with Isopropyl Alcohol to thoroughly clean the casters.
 7. After cleaning all casters, carefully tilt the platform upright.
 8. Un-pin and lower the drive assemblies.
 9. Re-install the payload structure if it was removed.
 10. Re-install the two side skins you removed earlier.
 11. Clean the side skins if needed.

LD Platform Cart Transporter Casters

The cart casters should be checked every 3 months. If they show signs of cracking, excessive wear, or any damage they should be replaced.

Front Caster Removal

The two front casters are identical, and are mounted to the transporter in the same way.



Figure 10-25. Front Cart Caster Screw Assembly

1. Remove the M10 screw and washer holding the caster to the cart.
Threadlocker was used on this screw during assembly.
Retain the screw, washer, and lock washer for mounting the new caster.
2. Remove the caster from the cart.

Front Caster Installation

1. Put the new caster in place, and attach with the M10 screw and washers you removed from the old caster.
Use Loctite 263 on the screw.
2. Torque to 73.2 N·m (54 ft-lbf).

Rear Caster Removal

The two rear casters are the same as each other, but different from the front casters, due to the fact that the rear casters have brakes.

1. Remove the top plate of the cart. See Removing Top Plate on page 156.
2. Unscrew the lock nut from the axle screw going through the caster wheel.
3. Remove the axle and caster wheel.

The axle screw, lock nut, and caster wheel can be discarded.

4. Loosen the outer brake-adjust jam nut at the actuator bar for the caster you are replacing.

See Figure 10-27.

Lift the cable and brake-adjust assembly out of the slot in the actuator bar.

5. Push the inner wire into the brake cable housing until the brake pin, which presses against the caster wheel surface, slides out of the caster mounting screw.




Figure 10-26. Brake Pin

Callout	Description	Callout	Description
A	Shaft of pin slides inside caster mounting screw	C	Flat top of blunt end retains spring
B	Blunt end passes against caster wheel	D	Brake cable wire, with ball end, fits into slot and hole

6. Remove the brake pin with spring from the inner brake cable wire.
Save the brake pin and spring for reassembly.
7. Pull the brake cable inner wire up far enough to be out of the way for removing the caster mounting screw.
8. Unscrew the caster mounting screw, to remove the caster assembly from the cart body.
Retain the caster mounting screw and lock washer for mounting the new caster.

Rear Caster Installation

1. Unscrew the lock nut from the axle going through the new caster wheel.
Retain the lock nut for reassembly.
2. Remove the axle and caster wheel from the caster. Do not discard.
Retain the axle and caster wheel for reassembly.
3. Attach the caster body to the cart body using the caster mounting screw and lock washer previously removed.
Take care not to damage the brake cable inner wire.

NOTE: Do not use threadlocker on the rear caster mounting screws.

Torque to 73.2 N·m (54 ft-lbf).

4. Push the brake cable inner wire back into the cable housing, so the ball end slides out of the caster mounting screw.
5. Make sure the spring, previously removed from the brake pin, is in place on the brake pin. The wide end goes up, against the caster mounting screw.
6. Insert the ball end of the inner wire into the hole in the brake pin, with the inner wire in the slot above the hole.
7. Slide the brake pin up inside the caster mounting screw, and hold it in place for the next step.
8. Install the caster wheel into the caster frame with the axle screw.
Fasten with the lock nut, previously removed.
Torque the lock nut to 41 N·m (30 ft-lbf). Ensure that the wheel spins freely.
The wheel will hold the brake pin inside the caster mounting screw, so it can't fall out.
9. Pull the inner wire of the cable through the actuator bar, and lock in place with the jam nut previously removed. Use Loctite 242 on the jam nut.

Cart Brake Release

Refer to the following figure for replacement and adjustment.

The Cart Brake Release consists of the lever cable with handle, and the caster brake system.




Figure 10-27. Internal Brake-Release Mechanism

Callout	Description	Callout	Description
A	Right Brake Cable	F	Actuator Bar
B	Right Brake Adjust	G	Actuator Bar Hard Stop
C	Lever Cable	H	Left Brake Cable
D	Pulley	I	Left Brake Adjust
E	Lever Cable Anchor	K	Lever Cable Clamp

Replacing Brake Lever Cable

To replace the cart brake-release cable:

1. Remove the cart top plate. See Removing Top Plate on page 156.
2. Disconnect the end of the cable from the brake control mechanism.
 - a. Disconnect the inner wire from the lever cable clamp.
 - b. Disconnect the lever cable from the lever cable anchor.
3. Feed the lever cable out through the hole in the horizontal back bar of the cart.
You will need to cut the cable tie at the saddle.
4. Disconnect the brake-release lever from its mounting place.
This will vary, depending on how and where you mounted it.

Adjusting the Lever Cable

The brake lever cable needs to be adjusted so there is no excess slack, but so the brakes are engaged when the lever is not being actuated.

The brake lever cable should be adjusted at the lever cable clamp, shown in the preceding figure. There should be just enough slack so the actuator bar touches its hard stop.

Adjusting the Caster Brake Cables

The two caster brake cables are adjusted at the factory. They will normally not need to be adjusted by the user.

If any adjustment is needed, refer to the preceding figure for the adjustment location. The brake pins should be able to go down as far as the caster surface allows, without any slack.

After the caster cables are adjusted correctly, ensure that the actuator bar just touches its hard stop. This will keep the actuator bar in position if you have to adjust the lever cable.

LD Platform Core

The LD Platform core is an enclosed unit, with internal fans as the only moving parts.

1. Access the payload bay. Refer to Accessing the Payload Bay on page 156.
2. Remove the inner rear cover.
3. Unlatch and open the battery compartment door, at the rear of the platform.
The battery compartment door is capable of being locked. You may need to unlock it.
4. Disconnect the battery power and data cables from the rear of the battery.
5. Disconnect all of the cables that are attached to the top portion of the LD Platform core.
Refer to Standard Platform Connections on page 89.
6. Remove the core mounting bracket from around the LD Platform core.

This is two pieces, held in place with four screws down into the chassis, with four more going sideways into the LD Platform core itself. Retain all of these screws for installing the new LD Platform core.

See the following figure:




Figure 10-28. Core Mounting Bracket

7. Remove the Sonar 1 cable from the core.

This cable is too short to allow the core to be lifted, until the cable is removed.

8. Gently lift the LD Platform core up, until you have access to the internal connections.
9. Remove all of the cables that are attached to the internal LD Platform core connector panel.

The Left Motor and Right Motor connectors use the same type of plug, and can be inadvertently reversed. Ensure that you can identify the left from the right.

See Internal LD Platform Core Connections on page 105.

10. Remove the old LD Platform core.
11. Connect all of the cables that were attached to the internal LD Platform core connector panel to the new core internal connector panel. See Figure 6-12.
Wait until after the next step to reconnect the Sonar 1 cable.
12. Put the core into the chassis.
13. Connect the Sonar 1 cable to the core.
14. Install the core mounting brackets around the new LD Platform core.
Using the screws and washers you removed from the old core, put four screws into the sides of the LD Platform core, with four more going down into the platform chassis.
15. Reconnect all of the cables to the top portion of the LD Platform core.
Refer to Standard Platform Connections on page 89.
16. Reconnect the battery power and data cables to the battery.
17. Close and latch the battery compartment door.
18. Reinstall the inner rear cover.
19. Reinstall the platform top plate and Latching Mechanism cover.
Refer to Accessing the Payload Bay on page 156.
20. Dispose of the old core according to local and national regulations concerning electronic components.

E-Stop and Safety Laser Commissioning

Under normal circumstances, the AIV is commissioned at the factory, and will not need to be re-commissioned. However, you must redo the E-Stop Commissioning and the Safety Laser Commissioning procedures under the following circumstances:

- If the core gets replaced, it will be necessary to redo the E-Stop Commissioning and the Safety Laser Commissioning procedures.
- If the hardware detects a failure, the AIV may automatically decommission itself, and the AIV will have to be re-commissioned to recover. In this event, ARAM will display a fault popup in MobilePlanner.
- If you are using a user-supplied E-Stop.

- Some customers have expressed a desire to perform the commissioning procedures on a regular basis as part of their preventive maintenance process.

NOTE: After performing either of these tests, you can access the other test by clicking **Next Test** on the final screen.

E-Stop Commissioning

This procedure verifies that the E-Stop circuitry is triggered when the E-Stop button is pressed. This is verified by ensuring that you hear the brakes activate after pressing the E-Stop button.

1. Ensure that the E-Stop button is NOT depressed before starting.
2. From the MobilePlanner software, select:

Main Menu > Robot > Safety Commissioning

3. Follow the on-screen instructions to complete the test. You can print a certificate after successful completion of the commissioning.

Safety Laser Commissioning

This procedure verifies that the safety scanning laser reports speed zone information correctly, and that the E-Stop circuitry is tripped when an obstacle that should be detected by the laser is placed in front of the AIV. The speed zones are listed in the following table. (When you press the Drive button in the wizard, the wizard will display the maximum AIV speed.)

	Maximum Speed (mm/s)	
Zone	LD-105CT	LD-130CT
0	225	150
1	450	300
2	675	450
3	900	600
4	1125	750
5	1350	900
6	1350	900
7	1350	900

1. From the MobilePlanner software, select:
Main Menu > Robot > Safety Commissioning
2. Follow the on-screen instructions to complete the test. You can print a certificate after successful completion of the commissioning.

Chapter 11: Technical Specifications

11.1 Dimension Drawings




Figure 11-1. Overall LD Platform Cart Transporter Dimensions (units are mm)




Figure 11-2. Coupling Plate Dimensions, Arms Removed, (A) Through hole (units are mm)




Figure 11-3. Cart Dimensions, (A) Threads (units in mm)

If you have a factory-supplied cart, these preceding dimensions show where you will attach your payload.


11.2 Specifications

LD Platform Cart Transporter Physical

Description	Specification
Physical	
Overall Length (with HMI post)	894 mm
Width (at side lasers)	1073 mm
Height (body)	383 mm
Overall Height (with HMI post)	1393 mm
Weight (with battery)	81 kg (179 lb)
Body clearance	50 mm

Description	Specification
Rating	
IP Rating	IP20
Cleanroom rating	Fed Class 100, ISO Class 5
Suspension	
Drive wheels	2 grey non-marking foam-filled rubber
Wheel diameter	200 x 50 mm nominal
Brakes	2 (one each axle)
Steering	Differential
Passive Casters	2 front, 2 rear, spring-loaded
Caster diameter	75 mm nominal

LD Platform Cart Transporter Performance

Description	Specification
Performance	
Max payload	LD-105CT: 105 kg (231 lb) LD-130CT: 130 kg (287 lb)
Run-time	15 h continuous, approx.
Swing radius	Platform or Platform and Cart: 698.5 mm
Turn radius	0 mm
Translational speed, max	LD-105CT: 1350 mm/s (53.1 inches/s) LD-130CT: 900 mm/s (35.4 inches/s)
Traversable step	5 mm with cart, 130 kg
Traversable gap	5 mm with cart, 130 kg
 CAUTION: PROPERTY DAMAGE RISK The LD Platform Cart Transporter with a cart is capable of driving over a gap or step of 5 mm (0.2 inch) at a speed of 250 mm/s, but this should not be regarded as normal use. Regular driving over such gaps or steps will shorten the lifespan of the drivetrain components.	
Minimum floor flatness	F _F 25 (based on the ACI 117 standard)
NOTE: ACI 117 is the American Concrete Institute's standard for concrete floors. F _F is flatness, F _L is the level. Higher F _F numbers represent flatter floors. F _F 25 is a fairly lenient specification.	

Description	Specification
Battery	
Run-time	15 hours, approx., no payload
Duty cycle	80%
Weight	19 kg (42 lb)
Voltage	22-30 VDC
Capacity	72 Ah
Energy	1.84 kWh nominal
Recharge time	4 h, approx.
Life span	Approximately 2000 Cycles
Sensors	
Safety Scanning Laser	1 at front of platform, 200 mm (7.9 inches) height 240°, 15 m range, Class 1, eye-safe PLd Safety per ISO-13849
Side Lasers	2 on horizontal tubes of HMI post 270°, 4 m range, Class 1, eye-safe
Low Level Laser	1 at front of platform, in bumper 270°, 4 m range, Class 1, eye-safe
Coupling Laser	1 on platform deck, passing through the top plate into the coupling plate 270°, 4 m range, Class 1, eye-safe
Rear-facing laser	1 on HMI post 270°, 4 m range, Class 1, eye-safe
Sonar (Each pair is one emitter and one receiver)	2 pairs at rear of platform, 2 m range
Bumper	1 at front of platform, triggers 4 sensors
Position encoders	2 encoders (one each wheel) 2 Hall sensors (one each wheel)
Analog gyroscope (core)	320°/s max rotation
Acuity localization (option)	1 camera on HMI post Operator Panel

Battery Output

Nominal	Qty	Actual	Maximum Current	Description
5 VDC	1	5±5% VDC	1 A	Switched Aux power

Nominal	Qty	Actual	Maximum Current	Description
12 VDC	1	12±5% VDC	1 A	Switched Aux power
20 VDC	1	20±5% VDC	1 A	Switched Aux power
22 – 30 VDC	2	battery	4 A	Switched
22 – 30 VDC	1*	battery	10 A	Switched
22 – 30 VDC	1*	battery	10 A	Safe, Switched
* 10 A Switched and 10 A Safe, Switched share the 10 A of current.				

Cart

Description	Specification
Physical	
Length	592 mm
Width	846 mm
Height	480 mm
Weight	23 kg (50 lb)
Rating	
Caster ESD	ESD rated
Suspension	
Passive Casters	2 front, 2 rear, spring-loaded
Caster diameter	100 mm (4 inches) nominal
Caster Brakes	2 rear casters

Docking Station

Description	Specification
Current	8 A, thermal fuse built into power switch
Contacts	2
Voltage	100-240 VAC, 50/60 Hz
Power consumption	800 W
Short circuit current rating (SCCR)	1500 A
Humidity	5% to 95% non-condensing
Temperature	5 to 40°C (41 to 104°F)
Dimensions - WxDxH	349 x 369 x 315 mm

Description	Specification
with Floor plate	495 x 495.5 x 317 mm
Weight	8.2 kg (18 lb)
Mounting	Directly to floor, wall bracket (included), or on floor (free-standing) with included floor plate
Indicators	Power on - blue Charging - yellow
Connector	For out-of-platform battery charging

OMRON Corporation Industrial Automation Company
Kyoto, JAPAN

Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp
The Netherlands
Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark,
Singapore 119967
Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates,
IL 60169 U.S.A.
Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON ADEPT TECHNOLOGIES, INC.

4550 Norris Canyon Road, Suite 150, San Ramon, CA 94583 U.S.A.
Tel: (1) 925-245-3400/Fax: (1) 925-960-0590

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2017-2019 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. I612-E-05

Printed in USA
0219 (0117)

14766-000 G